



# **SC300**

## **Computerized Control System for High-speed Zigzag Sewing Machine**

06



## **Forewords**

Thank you for using our Computerized Control System for Special Sewing Machine.






It is appreciated that you do read this manual carefully in order to operate the machine correctly and effectively. If the user operates the machine contrary to regulations herein, thus cause loss to user or third party, we will not take responsibility. Besides, you should keep this manual for future use. For any fault or problem of machine, please ask the professionals or the technicians authorized by us for repair service.











## Safety Matters for Attention








### 1. Signs & Definitions of Safety Marks







This User's Manual and the Safety Marks printed on the products are for you to use this product correctly so as to be away from personal injury. The signs and definitions of Marks are shown in below:








 Danger	The incorrect operation due to negligence will cause the serious personal injury or even death.
 Caution	The incorrect operation due to negligence will cause the personal injury and the damage to mechanism.
	This kind of marks is "Matters for Attention", and the figure inside the triangle is the content for attention. (Exp. The left figure is "Watch Your Hand!")
	This kind of mark is "Forbidden".
	This kind of mark means "Must". The figure in the circle is the contents that have to be done. (Exp. The left figure is "Ground!")

### 2. Safety Matters for Attention

 Danger	
	For opening the control box, please turn off the power and take away the plug from socket firstly, and then wait for at least 5 minutes before opening the control box. Touching the part with high voltage will cause the personal injury.
 Caution	
<b>Using Environment</b>	
	Try not to use this sewing machine near the sources of strong disturbance like high-frequency welding machine. The source of strong disturbance will affect the normal operation of the sewing machine.
	The voltage fluctuation shall be within $\pm 20\%$ of the rated voltage. The large fluctuation of voltage will affect the normal operations of sewing machine, Therefore a voltage regulator is needed in that situation.
	Working temperature: $5^{\circ}\text{C} \sim 35^{\circ}\text{C}$ . The operation of the sewing machine will be affected by environment with temperature beyond the above range.
	Relative Humidity: 45%~85%(No dew inside the machine), or the operation of sewing machine will be affected.
	The supply of compressed gas shall be over the consumption required by the sewing machine. The insufficient supply of compressed gas will lead to the

	abnormal action of sewing machine.
	In case of thunder, lightning or storm, please turn off the power and pull plug out the socket. Because these will have the influence on the operation of sewing machine
<b>Installation</b>	
	Please ask the trained technicians to install the sewing machine.
	Don't connect machine to power supply until the installation is finished. Otherwise the action of sewing machine may cause personal injury once the start switch is pressed at that situation by mistake.
	When you tilt or erect the head of sewing machine, please use both of your hands in that operation. And never press the sewing machine with strength. If the sewing machine loses its balance, it will fall into floor thus causes the personal injury or mechanical damage.
	Grounding is a must. If the grounding cable is not fixed, it may cause the electric-shock and mis-operation of machine
	The entire cables shall be fixed with a distance at 25mm away from the moving component at least. By the way, don't excessively bend or tightly fixed the cable with nails or clamps, or it may cause the fire or electric shock.
	Please add security cover on the machine head.

<b>Sewing</b>	
	This sewing machine can only be used by the trained staff.
	This sewing machine has no other usages but the sewing.
	When operating the sewing machine, please remember to put on the glasses. Otherwise, the broken needle will cause the personal injury in case the needle is broken.
	At following circumstances, please cut off the power at once so as to avoid the personal injury caused by the mis-operation of start switch: 1. Threading on needles; 2. Replacement of needles; 3. The sewing machine is left unused or beyond supervision
	At working, don't touch or lean anything on the moving components, because both of the above behaviors will cause the personal injury or the damage to the sewing machine.
	During working, if the mis-operation happens or the abnormal noise or smell is found at the sewing machine, user shall cut off the power at once, and then contact the trained technicians or the supplier of that machine for solution.

	For any trouble, please contact the trained technicians or the supplier of that machine.
<b>Maintenance &amp; Inspection</b>	
	Only can the trained technicians perform the repair, maintenance and inspection of this sewing machine.
	For the repair, maintenance and inspection of the electrical component, please contact the professionals at the manufacturer of control system in time.
	At following circumstances, please cut off the power and pull off the plug at once so as to avoid the personal injury caused by the mis-operation of start switch: 1.Repair, adjustment and inspection ; 2. Replacement of the component like curve needle, knife and so on.
	Before the inspection, adjustment or repair of any gas-driven devices, user shall cut off the gas supply till the pressure indicator falls to 0.
	When adjusting the devices needing the power supply and gas supply, users can't be too careful at following the entire Safety Matters for Attention.
	If the sewing machine damages due to the unauthorized modification, our company will not be responsible for it.





## Table of Content

1	General Information.....	1
1.1	Summary.....	1
1.2	Specification.....	1
1.3	Matters for Safe Using.....	1
1.4	The Preventions on Instruction.....	3
1.5	Operation Method.....	5
1.6	Model.....	5
1.7	Sewing Pattern List.....	5
2	Preparation before Sewing.....	8
2.1	Installation of Needle.....	8
2.2	Installation of Bobbin Case.....	8
2.3	Wind the Bottom Thread.....	9
2.4	Method for Putting Shuttle Core.....	11
2.5	Threading Method of Upper Thread.....	11
2.6	Adjustment of Cloth-feeding Length.....	12
2.7	Adjustment of Contraction Sewing.....	13
3	Operations.....	14
3.1	Basic Operations.....	14
3.2	Buttons.....	15
3.3	Before Setting Pattern.....	16
3.3.1	Set Max Swing of Needle.....	19
3.3.2	Setting of Base Line.....	22
3.3.3	Setting of the Feeding Amount.....	23
3.4	Main Interface.....	24
3.5	Patten Selection.....	25
3.5.1	Standard Pattern Selection.....	29
3.5.2	Customized Pattern Selection.....	29
3.5.3	Selection of the Saved Pattern.....	30
3.5.4	Continuous Sewing Selection.....	32
3.5.5	Cyclic Sewing Selection.....	33
3.6	Setting of Basic Pattern.....	34
3.6.1	Setting of Line.....	34
3.6.2	Setting of X-points Zigzag Sewing (X can be 2, 3 and 4).....	36
3.6.3	Set Scallop.....	38
3.6.4	Set Blind Stitch.....	40
3.6.5	Set Left T Sewing.....	42
3.6.6	Set Right T Sewing.....	44
3.6.7	Set Pattern 1.....	46
3.6.8	Set Pattern 2.....	48
3.6.9	Set Pattern 3.....	50
3.6.10	Set Pattern 4.....	52
3.7	Customized Pattern.....	53

3.7.1 Set Customized Pattern.....	54
3.7.2 Create the Customized Pattern.....	55
3.7.3 Copy Customized Pattern.....	55
3.7.4 Edit the Customized Pattern.....	56
3.8 Saved Pattern.....	57
3.8.1 Set the Saved Pattern.....	57
3.8.2 Register Pattern.....	59
3.8.3 Copy the Saved Pattern.....	60
3.9 Continuous Sewing.....	61
3.9.1 Set Continuous Sewing.....	61
3.9.2 Create Continuous Sewing.....	62
3.9.3 Copy Continuous Sewing.....	63
3.9.4 Edit Continuous Sewing.....	63
3.10 Cyclic Sewing.....	65
3.10.1 Set Cyclic Sewing.....	66
3.10.2 Create Cyclic Sewing.....	67
3.10.3 Copy Cyclic Sewing.....	68
3.10.4 Edit Cyclic Sewing.....	68
3.11 Sewing Mode Setting.....	71
3.11.1 Overlapped Sewing.....	72
3.11.2 Program Sewing.....	73
3.12 Set Reverse Sewing.....	75
3.12.1 Standard Reverse Sewing.....	77
3.12.2 2-points Contraction Sewing.....	79
3.12.3 Customized Reverse Sewing.....	81
3.12.4 Comparison of Reverse Sewing Patterns.....	84
3.13 Information Mode.....	84
3.13.1 Parameter Setting.....	86
3.13.2Parameter List.....	89
3.13.3 Parameter Recovery and Back-up.....	96
3.13.4 Default Parameter Recovery.....	98
3.13.5 Parameter Encryption.....	100
3.13.6 Counter.....	102
3.13.7 Display Setting.....	105
3.13.8 Software Version.....	108
3.13.9 Pattern Transfer.....	109
3.13.10 Alarm Records.....	112
3.13.11 Running Records.....	113
3.13.12 Formatting.....	113
3.13.13 Date and Time Setting.....	114
3.13.14 Password Mode.....	115
3.13.15 Software Update.....	121
3.14 Test Mode.....	121
3.14.1 LCD Test.....	123

---

3.14.2 Touching Panel Correction.....	123
3.14.3 Input Signal Test.....	124
3.14.4 Main Shaft Speed Test.....	124
3.14.5 Output Signal Test.....	125
3.14.6 Continuous Running.....	125
3.14.7 Swing/ Cloth-feeding Motor Origin Detection.....	126
3.14.8 Shuttle Adjustment.....	127
3.15 Manual Switches.....	128
4 Appendix 1.....	129
4.1 Warning Information List.....	129
4.2 Hint Information List.....	130
5 Appendix 2.....	135
5.1 Installation Size of Control Box.....	135
5.2 Installation Size of Touching Panel.....	136
5.3 SC300 Diagram.....	137



# 1 General Information

## 1.1 Summary

Computerized control system for high-speed zigzag sewing machine: 1) Adoption of the world leading AC servo control technology on main shaft motor provides high torque, good efficiency, stable speed and low noise; 2) Diversified design of control panel can meet the special requirement of users on attachment; 3) System adopts German style structure, which offers easy installation and maintenance to users.

## 1.2 Specification

用途	薄料~中厚料
最高转速	5000rpm
最大摆幅宽度	10mm
最大送布量	正逆 5mm (双步进) 有 (单步进) 无
切线	有 (双步进) 有 (单步进) 无
送布方式	标准送布(电子控制方式) (双步进) 有 (单步进) 无
电源	AC175~265V (50~60HZ)
功率	500W
数据记忆体	U 盘
缝制图案	20 种花样

## 1.3 Matters for Safe Using

### ● Working Environment

Do not use this control device in the following environments:

- Power Voltage
  - ◆ Voltage fluctuation beyond  $\pm 10\%$  of the standard voltage
  - ◆ Capacity of power supply doesn't meet the requirement
- Electrical Disturbance
  - ◆ Beside the wave launcher with strong electrical wave and magnetic field or the high cyclic machine.
- Temperature/ Humidity
  - ◆ Temperature below  $0^{\circ}\text{C}$  or above  $35^{\circ}\text{C}$
  - ◆ Outdoors or the area directly shined by sun

- ◆ Beside stove (heater).
- ◆ Relating humidity below 5% or above 95% or the area without dew
- Air
  - ◆ Dusty area or area with corrosive gas
  - ◆ Area that is easy to have air explosion or oil explosion
- Vibration
  - ◆ If the location of the sewing machine usually has excessive vibration, please move the control box to other place.

## ● Installation

- Control Box
  - ◆ Please install the control box according to the instruction
- Attachments
  - ◆ If other attachments are needed, please turn off the power and pull off the power plug.
- Power Cable
  - ◆ Do not press power cable with force or excessively twist power cable.
  - ◆ The power cables shall be fixed with a distance at 25mm away from the rotating component at least.
  - ◆ Before powering the control box, user shall carefully check the voltage of power supply and position of power input on control box. If the power transformer is used, user should also check it before powering the machine. At this moment, the power switch of sewing machine must be set as “Off”.
- Grounding
  - ◆ In order to avoid the noise disturbance and shock caused by electrical leakage, user should install the grounding cable.
- Attachments
  - ◆ If the electrical attachments are needed, please connect them to the proper positions.
- Disassemble
  - ◆ When removing the control box, user should turn off the power and pull off the power plug.
  - ◆ At pulling off the power plug, user should hold the plug and remove it, instead of pulling the power cable only.
  - ◆ The control box contains the dangerous high voltage power. For opening the control box, please turn off the power and take away the plug from socket firstly, and then wait for at least 5 minutes before opening the control box.

## ● Maintenance, Inspection and Repair

- Only can the trained technicians perform the repair and maintenance of this machine.
- When replacing the needles and shuttles, user has to turn off the power.
- Please use the spare parts from the authorized manufacturers

## ● Others

- Do not touch the rotating or moving part of the machine, especially the needle and belt, when the machine is working. User should also keep his/her hair away from those moving parts, so as to avoid the danger.
- Do not drop the control device on the floor, nor insert any stuff into the slots on the control box.
- Do not run the machine without the cover shells
- If this control device is damaged or unable to work normally, please ask the technicians to adjust or repair it. Do not run the machine when the problem is not solved.
- Please do not change or modify the control device without authorization.

● **Abandonment**






- Dispose it as common industrial trash.

● **Warning and Danger**

- The mistake operation may cause danger. For the serious level, please refer to the figure at below:

 <b>警告</b>	错误的行动可能会发生重伤或死亡。	 <b>注意</b>	错误的行动可能会发生伤害或房屋或财产的损害。
--	------------------	--	------------------------







- The meaning of the figure are shown at below:

	请遵照指示内容作业。		注意高压电 (电击) 的危险。
	注意高温。		务必接上接地线。
	绝对不要执行。		


**1.4 The Preventions on Instruction**



- |   |
|---|
| 1、When you leave the machine, please turn it off. |
|---|


	
<p>3、 If user needs tilt the head or replace the needle or thread the upper thread, please turn off the power</p> 	<p>4、 Grounding the machine with ground cable.</p> 
<p>5、 Do not use the household terminal block to let machines to share one power supply</p> 	<p>6、 For opening the control box, please turn off the power and take away the plug from socket firstly, and then wait for at least 5 minutes before opening the control box.</p> 
<p>8、 Please keep it away from the machine creating the high cyclic disturbance</p> 	<p>9、 If user needs the external signal socket to connect the attachments, the connecting wire shall be as short as possible. The long cable may cause the wrong operation. And the connection cable shall be the isolated cable</p>



	
<p>10.、 If the fuse is burnt, please solve the problem before replacing a new one with same capacity.</p>	

## 1.5 Operation Method

The touching panel of zigzag sewing controller adopts the advanced touching operation technology, whose friendly interface and easy control bring the revolutionary changes to the daily usage of the users. For performing the relating operations, user can use his fingers or other objects to touch the screen.



警告












Don't use the sharp object to touch the screen so as to avoid causing the permanent damage to the touching panel.










## 1.6 Model

The main difference among 2290S-SR/S/B is the cloth-feeding method, which are stepping motor, solenoid and lever respectively. Therefore, the relating function of products is depending on the specific type of machine.

## 1.7 Sewing Pattern List

Name	Stitch Form	Stitch Number	Max Swing Width
------	-------------	---------------	-----------------

Line			1	-
2-point zigzag			2	10
3-point zigzag			4	
4-point zigzag			6	
Scallop (Right)	Standard		24	
	Lunar			
	Average 24 Stitches			
	Average 12 Stitches		12	
Scallop (Left)	Standard		24	
	Lunar			
	Average 24 Stitches			

	Average 12 Stitches		12
Blind Stitch Form (Left)			2+a
Blind Stitch Interval (Right)			2+a
Left T (单步进没有)			3
Right T (单步进没有)			
Pattern 1 (单步进没有)			6
Pattern 2 (单步进没有)			
Pattern 3 (单步进没有)			
Pattern 4 (单步进没有)			
Customized Pattern	-		500


## 2 Preparation before Sewing

### 2.1 Installation of Needle



警告

In order to avoid the personal injury due to the sudden move, user should perform the operation after the motor stops completely.




- 1) Turn the wheel to lift the needle to the highest position.
- 2) Loosen the needle screw ② and turn the slot ③ on the needle ① to front.
- 3) Insert the needle in the direction of arrow deeply
- 4) Fix the needle screw ②.
- 5) Make sure the slot ③ on the needle is facing the front.

### 2.2 Installation of Bobbin Case



警告

In order to avoid the personal injury due to the sudden move, user should perform the operation after the motor stops completely.




- 1) Turn the wheel to lift the needle to the highest position.
- 2) Draw the handle ① on the bobbin case and take it off

## 2.3 Wind the Bottom Thread



**In order to avoid the personal injury due to the sudden move, user should perform the operation after the motor stops completely.**




- 1) Put shuttle core on the winding shaft ⑤.
- 2) Thread in order from ① to ⑧, and then wind the thread on the shuttle core for several loops.
- 3) Press the winding lever ⑥ in direction A and run the sewing machine. The shuttle core will rotate in direction C and the thread will be wound on the shuttle core. After the winding, the winding shaft ⑤ will stop automatically.
- 4) Remove the shuttle core and use cutting plate ⑧ to cut thread
- 5) When adjusting the winding amount of bottom thread, user needs loosen the screw ⑦, move the winding adjustment plate ⑥ in direction A or B

and fix the screw ⑦.

Direction A: Reduce the amount

Direction B: Increase the Amount




- 6) If user can not wind the thread smoothly, user should loosen the nut ④, turn the winding tension device and adjust the height of the thread tension plate ②.

The standard position is that the center height of shuttle core is same as that of tensions plate.

When the lower side has more threads, user needs move thread tension plate ② in direction A, or user should move the tension plate to direction B.

After adjustment, fix the nut ④.



When adjusting the bottom thread tension, user needs turn the thread tension nut ③ and adjust it.


**[Note 1] At winding the bottom thread, please tighten the thread between the shuttle core and tension plate ② firstly.**

**[Note 2] When winding the bottom thread not in the status of sewing, user needs remove the upper thread on the slot of down jump thread rod and take out the shuttle core from the shuttle**


## 2.4 Method for Putting Shuttle Core



**In order to avoid the personal injury due to the sudden move, user should perform the operation after the motor stops completely.**



- 1) Turn the wheel to lift the needle to the highest position.
- 2) Pull the about 5cm thread from the shuttle core and put them into the bobbin case.
- 3) Thread in the order of the number. Pull thread form the opening. Pulling the bottom thread will have the shuttle core to rotate in the direction of arrow.
- 4) Draw the handle ① on bobbin case.
- 5) At this moment, put thread from the lower shield handle and insert it into the inner shuttle shaft
- 6) Close the handle on the bobbin case



Usage Method of Thread Hole on Bobbin Case:


- 1) Hole A is used at the sewing beyond the 2-points zigzag sewing and scallop zigzag sewing.
- 2) Hole B is used at the 2-points zigzag sewing and scallop zigzag sewing mainly.

**[Note] At Hole B, after machine cuts the long fiber thin thread, the first few stitches may be hard to get knotted. Therefore, please use other thread hole or start sewing from right**

## 2.5 Threading Method of Upper Thread




**In order to avoid the personal injury due to the sudden move, user should perform the operation after the motor stops completely.**





- 1) Turn the wheel to lift the needle to the up position
- 2) Thread according to the number order on picture.
- 3) Draw the thread out of needle at about 10cm.

## 2.6 Adjustment of Cloth-feeding Length



- 1) Use the operation panel to adjust the length of feeding cloth.

Normal Feeding: Press  to have access to the interface for setting normal feeding.


Contrary Feeding: Press  to have access to the interface for setting contrary feeding.

- 2) At reverse sewing, press the feeding bar ① to down position for perform the reverse sewing. The bar will return to the original position after you release it. Then the machine will return to feed cloth normally.

**【注】** 只有双步进款有此功能。




## 2.7 Adjustment of Contraction Sewing



The contraction sewing is to operate the feeding bar to reduce the feeding interval to stop sewing at the sewing start or sewing end.

1) Adjust the feeding length via the operation panel.

Contrary Feeding: Press  to have access to the interface for setting the contrary feeding. Set the contrary feeding amount at 0, then it will turn to the stop sewing.

3) The stop sewing is related to the normal sewing. Please adjust it according to the sewing condition.

**【注】** 只有双步进有此功能。

## 3 Operations


### 3.1 Basic Operations

#### 1、 Turn on Power Switch


When the needle rod is not at the upper position, the system will give “Needle Up Posi. Error”. At this moment, user has to turn the wheel to move the needle rod to the upper position.

#### 2、 Select the Pattern

Select the pattern for sewing at current interface.



#### 3、 Start Sewing




The pedal has four levels.







- 1) Stepping front part of pedal slightly is for slow speed sewing (B).
- 2) Stepping front part of pedal again is for high speed sewing (A) (When the auto reverse sewing switch is set, the machine will start high speed sewing after the reverse sewing).
- 3) Step the pedal slightly and release, the machine will stop (C) (The needle stops at upper or down position)

- 4) Stepping the rear part of pedal is to lift the presser ① ,  
stepping that part again is to cut thread ② .

### 3.2 Buttons




## Functions:

No.	Functions	Content
A	Title	The left part of it will display the title of interface, while the right part of it will display the date and time. When user presses a button, the left part of the title will be refreshed to the function description of that button.
B	Shift	Shift the main operation interface in cycle
C	Half-stitch Compensation	Used for the half-stitch compensation at sewing <b>[Note]: User can shift it between the half-stitch and one-stitch via parameter 「Others」 -&gt; 「Panel Compensation Setting」.</b>
D	Information	Press it to have access to the interface of information mode.
E	Light Switch	Set the status of light  : Light On  : Light Off
F	Trimming Switch	Set the action of knife  : Trimming Permitted  : Trimming Forbidden
G	Auto Trimming Display	Used for displaying the trimming status in current sewing mode.  : No Auto Trimming  : Auto Trimming
H	Counter	Display the information of trimming counter or the bottom thread counter <b>[Note]: Use 「Counter」 -&gt; 「Counter Display」 to shift the type of counter.</b>
I	Max Speed Limits	Limit the Max sewing speed <b>[Note]: it is affected by parameter 「Special」 -&gt; 「Max Speed」.</b>


### 3.3 Before Setting Pattern



- When user uses the presser, needle plate and feeding device beyond the standards, the incorrect value may cause the crashes between needle and needle plate (thus causes the needle-breakage) or the feeding device and needle plate. Therefore, user has to follow the rules on the value limits according to the scale used.
- At standard, the Max swing of needle is 8mm.
- The Max feeding is 5mm
- After the change of scale, user needs to adjust the interval among needle, presser and needle plate, as well as the interval between needle plate and feeding device to more than 0.6mm.



When power is on, the system will display the Max swing limits, base line, normal feeding limits and contrary feeding limits.



**Functions:**

No.	Description
A	Max Swing Limits (The figure will change when the pointed position is different)
B	Base Line
C	Max Contrary Feeding Limits

D	Max Normal Feeding Limits
---	---------------------------


[Note] Use


parameter 「General Setting」 -> 「Swing Limits Display」 to turn off the display of the limits value at power-on.

【注】单步进没有 C、D 提示。


## Setting Method:

### 1、 Have access to Information Mode

Press  in main interface to have access to the interface of information mode




### 2、 Have access to parameter setting

In the interface of information mode, press  to have access to the interface for setting parameters.




### 3、 Select「General Setting」parameter

In the parameter setting interface, select 「General Setting」




### 4、 Parameter Setting

Open this parameter group. Then user can set the parameters like Max Swing, Base Line, Max Contrary Feeding Amount and Max Normal Feeding Amount.



## 3.3.1 Set Max Swing of Needle


- There are two ways to limit the max needle swing:
  - 1) Set the swing width at both sides (Symmetric in center)
  - 2) Point the positions at both sides



### Setting Method:

#### 1、Select [Swing Type]

Follow the steps 1~4 at above to enter the interface for setting the general parameters. Select “Swing Type” and press “P1-0”.






### 2、Set Swing Type


As the picture shows, user can select “Center Symmetric” or “L/R Symmetric”.

Press  to confirm the selection.





### 3、Select “Center Symmetric Swing Limits”

Return to the setting interface of general parameter and select “Center Symmetric Swing Limits” and press “P1-1”.




### 4、Set “Center Symmetric Swing Limits”

Use number keys to input the value and press  to confirm.





### 5、 Select “Swing Left Limits”

When the swing type is set at “L/R Symmetric”, user needs select “Swing Left Limits” and press “P1-2”.




### 6、 Set “Swing Left Limits”

Use number keys to input the value and press  to confirm.




### 7、 Set “Swing Right Limits”

The setting method is same as that in above.



## 3.3.2 Setting of Base Line


- User can set the position of the base line at Left, Right or Center.




### Setting Method:


#### 1、Select “Base Line Position”

Enter the interface for setting general parameter, select “Base Line Position” and press “P1-4”.



#### 2、Set Position of Base Line

As shown in right picture, there are “Center”, “Left” and “Right”. Press  to confirm the selection.



### 3.3.3 Setting of the Feeding Amount


- When user uses the different standard parts, he can set the max feeding in normal direction and the max feeding in contrary direction.

**【注】** 本节内容只有双步进款有此功能。


## Setting Method:


### 1、 Select “Contrary Feeding Limits”

Have access to the interface for setting general parameters, select “Contrary Feeding Limits” and press “P1-5”




### 2、 Set “Contrary Feeding Limits”

Use number keys to input the value and press  to confirm.




### 3、 Set “Normal Feeding Limits”

Refer to the operations in steps 1~2 and select “Normal Feeding Limits” to input value.




## 3.4 Main Interface


- Turn on the power. The interface at operation panel will be the main interface before the power-off.


- Press  to shift the main interface in the following order (The contents displayed may be a little different, which are depended on the specific setting).

### Example:

We use 2-points zigzag (Program Sewing Mode) as the example:




[Note 1]: if you select free sewing mode, the system will not enter the sewing mode setting interface at pressing .

[Note 2]: if you select overlapped sewing mode, the system will not enter the interface for setting reverse sewing at pressing .

## 3.5 Patten Selection

How to select a pattern for sewing:

- Shift to interface for selecting the shape, where user can select 20 basic patterns, customized patterns, memory patterns, continuous sewing or cyclic sewing. (单步进为 14 个)
























**Functions:**

No.	Functions	Contents
A	Current Pattern	Display the pattern selected currently
B	Pattern Selection Area	<ul style="list-style-type: none"> <li>Select 20 basic patterns, customized patterns, memory pattern, continuous sewing and cyclic sewing. (单步进为 14 个)</li> </ul>
C	Page Key	Turn the pages for display


**Description of Pattern Selection:**

Figures	Description
	Line
	2-points Zigzag

	3-points Zigzag
	4-points Zigzag
	Right Standard Scallop
	Right Lunar Scallop
	Right 24-stitch Average Scallop
	Right 12-stitch Average Scallop
	Left Standard Scallop
	Left Lunar Scallop
	Left 24-stitch Average Scallop
	Left 12-stitch Average Scallop
	Left Blind Stitch


	Right Blind Stitch
	Left T Sewing(单步进没有)
	Right T Sewing(单步进没有)
	Pattern 1(单步进没有)
	Pattern 2(单步进没有)
	Pattern 3(单步进没有)
	Pattern 4(单步进没有)
	Customized Pattern
	Saved Pattern
	Continuous Sewing






### 3.5.1 Standard Pattern Selection

- In shape setting interface, user can press basic pattern button. There are 20 basic patterns for selection. After the successful selection, the system will enter the interface for setting shape.




【注】单步进没有  和  设置。



### 3.5.2 Customized Pattern Selection

- In the shape setting interface, press  to have access to the interface for selecting customized pattern.
- At most 500 customized patterns can be saved.

**[Note]: If the operation panel has no customized pattern, the system will enter the interface for creating customized pattern.**



### Functions:

No.	Functions	Contents
A	Pattern Display	Display the shape of the selected pattern
B	New Pattern	Create a new customized pattern
C	Copy	Copy the customized pattern that is selected
D	Single Selection/ multi-selection	Shift the sing-selection / multi-selection. The multi-selection enables user to select several patterns at one time, which is used at pattern deletion  : Single Selection  : Multi-selecn tion
E	Deletion	Delete the selected pattern. <b>[Note] The pattern being embroidered can not be deleted</b>
F	Pattern Selection Area	Display the number of the customized pattern saved in operation panel.
G	Page No.	Display current page/ total page
H	Cancel	Cancel the current operation and quit
I	Enter	Confirm the selection of current pattern and have access to the interface for setting the customized pattern. <b>[Note] This button can only be used at single selection status</b>


### 3.5.3 Selection of the Saved Pattern

- After the registration, the basic patterns or the customized patterns will become the saved pattern. The parameters, sewing mode and reverse sewing of the saved pattern are


independent.

- At most, 500 saved patterns can be registered in the memory.





- In the interface of setting shape, user can press  to have access to the interface for selecting the saved patterns.

**[Note] If the operation panel doesn't contain any saved pattern, the system will display "No Registered Pattern in Memory".**




**Function:**


No.	Functions	Contents
A	Pattern Display	Display the shape of the selected pattern
B	Free Memory	Display the rest free memory
C	Single Selection/ multi-selection	Shift the sing-selection / multi-selection. The multi-selection enables user to select several patterns at one time, which is used at pattern deletion  : Single Selection  : Multi-selection
D	Deletion	Delete the selected pattern. <b>[Note] The pattern being embroidered can not be deleted</b>
E	Pattern Selection Area	Display the number of the available saved pattern in operation panel.
F	Page No.	Display current page/ total page
G	Cancel	Cancel the current operation and quit
H	Enter	Confirm the selection of current pattern and have access to the interface for setting the saved pattern. <b>[Note] This button can only be used at single selection status</b>

### 3.5.4 Continuous Sewing Selection



- The continuous sewing is the function to connect the different patterns or sew the pattern whose estimated stitch number is over 500 stitches. The continuous sewing pattern can be recognized by the system as one pattern.

- In the interface of setting shape, user can press  to have access to the interface for selecting the continuous sewing.
- At most, 20 continuous sewing patterns can be saved.

**[Note] If the operation panel doesn't contain any continuous sewing pattern, the system will enter the interface for creating the continuous sewing pattern.**



#### Functions:


A	New Pattern	Create a new continuous sewing pattern
B	Copy	Copy the selected continuous sewing pattern
C	Single Selection/ multi-selection	Shift the sing-selection / multi-selection. The multi-selection enables user to select several patterns at one time, which is used at pattern deletion  : Single Selection  : Multi-selection
D	Deletion	Delete the selected pattern. <b>[Note] The pattern being embroidered can not be deleted</b>
E	Pattern Selection Area	Display the number of the continuous sewing pattern saved in operation panel.

F	Page No.	Display current page/ total page
G	Cancel	Cancel the current operation and quit
H	Enter	Confirm the selection of current pattern and have access to the interface for setting the continuous sewing pattern. [Note] This button can only be used at single selection status


### 3.5.5 Cyclic Sewing Selection

- Cyclic sewing is to sew the different patterns in order.





- In the interface of setting shape, user can press  to have access to the interface for selecting the cyclic sewing.
- At most, 20 cyclic sewing patterns can be saved.

[Note]: If the operation panel doesn't contain any cyclic sewing pattern, the system will enter the interface for creating the cyclic sewing pattern.



#### Functions:

A	New Pattern	Create a new cyclic sewing pattern
B	Copy	Copy the selected cyclic sewing pattern
C	Single Selection/ multi-selection	Shift the sing-selection / multi-selection. The multi-selection enables user to select several patterns at one time, which is used at pattern deletion  : Single Selection  : Multi-selection


D	Deletion	Delete the selected pattern. <b>[Note] The pattern being embroidered can not be deleted</b>
E	Pattern Selection Area	Display the number of the cyclic sewing pattern saved in operation panel.
F	Page No.	Display current page/ total page
G	Cancel	Cancel the current operation and quit
H	Enter	Confirm the selection of current pattern and have access to the interface for setting the cyclic sewing pattern. <b>[Note] This button can only be used at single selection status</b>

## 3.6 Setting of Basic Pattern

How to set the swing width, base line, cloth feeding amount and speed of basic pattern


- The basic patterns are the 20 default patterns saved in the system at beginning.











### 3.6.1 Setting of Line



【注】单步进没有  和  设置。

Functions:



A	Current Pattern	Display the current patterns. User can press it to return to the interface for selecting the shape
B	 Display & Setting of Max Speed	Display the Max speed. Press it to have access to the setting interface of speed.


C	 Display & Setting of Normal Feeding	Display the normal feeding value. Press it to have access to the setting interface of the normal feeding
D	 Display & Setting of Base Line Position	Display the position of the base line. Press it to have access to the interface for setting the base line The figure displayed can be changed via 「General Parameter」 -> 「Base Line Position」 : Left:  Center:  Right: 
E	 Display & Setting of Contrary Feeding	Display the contrary feeding value. Press it to have access to the setting interface of the contrary feeding
F	Sewing Mode	Display the current sewing mode. Press it to have access to the interface for setting the sewing mode
G	Front Reverse Sewing Type	Display the front reverse sewing type of the current pattern <b>[Note]: When the front reverse sewing switch is at Off, the front reverse sewing type will not be displayed.</b>
H	Back Reverse Sewing Type	Display the back reverse sewing type of the current pattern <b>[Note]: When the back reverse sewing switch is at Off, the back reverse sewing type will not be displayed.</b>
I	Front Reverse Sewing Switch	Turn on/off the front reverse sewing  : Effective  : Ineffective
J	Back Reverse Sewing Switch	Turn on/off the back reverse sewing  : Effective  : Ineffective
K	Registration	Register the current pattern. <b>[Note] The registration is only available at free sewing or overlapped sewing.</b>

### Instructions on Parameter Setting:





At here, we will explain how to set the Max Speed and the Position of Base Line. The method for setting the normal feeding amount and contrary feeding amount is same as that of Max Speed


### 1、 Set the Max Speed

In the interface for setting shape, user needs press  to have access to the interface for setting the Max Speed. Use the number keys to input value and press  to finish the operation.




### 2、 Set Base Line

In the interface for setting shape, user needs press  to have access to the interface for setting the Base Line. Use  or  to set the position of the base line. The needle position will change along with the setting. Press  to finish the operation.



## 3.6.2 Setting of X-points Zigzag Sewing (X can be 2, 3 and 4)














At here, we will introduce how to make 2-points zigzag sewing.








【注】单步进没有  和  设置。

## Functions:





A	Current Pattern	Display the current pattern. Press it to return to the shape selection interface.
B	 Display and Setting of Swing Width	Display the swing width. Press it to have access to the interface for setting the swing width.
C	 Display and Setting of Base Line	Display the position of the base line. Press it to have access to the interface for setting the base line The figure displayed can be changed via 「General Parameter」 -> 「Base Line Position」 : Left:  Center:  Right: 
D	 Display & Setting of Max Speed	Display the Max speed. Press it to have access to the setting interface of speed.
E	 Display & Setting of Normal Feeding	Display the normal feeding value. Press it to have access to the setting interface of the normal feeding.
F	 Display & Setting of Contrary Feeding	Display the contrary feeding value. Press it to have access to the setting interface of the contrary feeding.
G	 Display & Setting of Start Point	Display the position of the start point. Press it to have access to the interface for setting the start point.  : Random  : Right  : Left
H		Display the position of the end point. Press it to have access to the interface for setting the end point.

	Display & Setting of End Point	 : Random  : Right  : Left
I	-	Refer to the description in Line Setting

## Instructions on Parameter Setting:



At here, we will explain how to set the swing width and the position of the start point. The setting method of the end point is same as that of the start point.


### 1、Set Swing Width

In the interface for setting shape, user needs press  to have access to the interface for setting the swing width, where user can use  or  to set the value. The needle will move along with the change of value. Press  to finish the operation.




### 2、Set Start Point

In the interface for setting shape, user needs press  to have access to the interface for setting the start point. Find a proper position and press  to finish the operation.










## 3.6.3 Set Scallop










We use the right standard scallop as the example.




【注】单步进没有和设置。

**Functions:**


A	Current Pattern	Display the current pattern. Press it to return to the shape selection interface.
B	 Display and Setting of Swing Width	Display the swing width. Press it to have access to the interface for setting the swing width.
C	 Display and Setting of Base Line	Display the position of the base line. Press it to have access to the interface for setting the base line The figure displayed can be changed via 「General Parameter」 -> 「Base Line Position」 : Left:  Center:  Right: 
D	 Display & Setting of Max Speed	Display the Max speed. Press it to have access to the setting interface of speed.
E	 Display & Setting of	Display the normal feeding value. Press it to have access to the setting interface of the normal feeding

	Normal Feeding	
F	 Display & Setting of Contrary Feeding	Display the contrary feeding value. Press it to have access to the setting interface of the contrary feeding
G	 Display & Setting of Start Point	Display the position of the start point. Press it to have access to the interface for setting the start point.  : Valley  : Peak
H	 Display & Setting of End Point	Display the position of the end point. Press it to have access to the interface for setting the end point.  : Left  : Right  : Random  : Valley
I	-	Refer to the description in Line Setting










### 3.6.4 Set Blind Stitch



We use the left blind stitch as example.



【注】单步进没有  和  设置。

**Functions:**


A	Current Pattern	Display the current pattern. Press it to return to the shape selection interface.
B	 Display and Setting of Swing Width	Display the swing width. Press it to have access to the interface for setting the swing width.
C	 Display and Setting of Base Line	Display the position of the base line. Press it to have access to the interface for setting the base line The figure displayed can be changed via 「General Parameter」 -> 「Base Line Position」 : Left:  Center:  Right: 
D	 Display & Setting of Max Speed	Display the Max speed. Press it to have access to the setting interface of speed.
E	 Display & Setting of	Display the normal feeding value. Press it to have access to the setting interface of the normal feeding


	Normal Feeding	
F	 Display & Setting of Contrary Feeding	Display the contrary feeding value. Press it to have access to the setting interface of the contrary feeding
G	 Display & Setting of Blind Stitch Number	Display the number of blind stitch. Press it to have access to the interface for setting the blind stitch.
H	-	Refer to the description in Line Setting


### Instructions on Parameter Setting:

We give the example on how to set the blind stitch number


#### 1. Set Blind Stitch Number

In the interface for setting shape, user needs press  to have access to the interface for setting the stitch number, where user can input the value via keyboard on screen. Press















 to finish the operation.







### 3.6.5 Set Left T Sewing(单步进没有此花样)




**Functions:**




A	Current Pattern	Display the current pattern. Press it to return to the shape selection interface.
B	 Display and Setting of Swing Width	Display the swing width. Press it to have access to the interface for setting the swing width.
C	 Display and Setting of Base Line	Display the position of the base line. Press it to have access to the interface for setting the base line The figure displayed can be changed via 「General Parameter」 -> 「Base Line Position」 : Left:  Center:  Right: 
D	 Display & Setting of Max Speed	Display the Max speed. Press it to have access to the setting interface of speed.
E	 Display & Setting of Normal Feeding	Display the normal feeding value. Press it to have access to the setting interface of the normal feeding
F	 Display and Setting of Compensation	Display the compensation value. Press it to have access to the interface for setting the compensation value.
G	 Display & Setting of Start Point	Display the position of the start point. Press it to have access to the interface for setting the start point.  : Left  : Right 1  : Right 2  : Random
H	 Display & Setting of	Display the position of the end point. Press it to have access to the interface for setting the end point.

	End Point	 : Left  : Right 1  : Right 2  : Random
I	-	Refer to the description in Line Setting
















### 3.6.6 Set Right T Sewing (单步进没有此花样)




#### Function:

A	Current Pattern	Display the current pattern. Press it to return to the shape selection interface.
B	 Display and Setting of Swing Width	Display the swing width. Press it to have access to the interface for setting the swing width.
C	 Display and Setting of Base Line	Display the position of the base line. Press it to have access to the interface for setting the base line The figure displayed can be changed via 「General Parameter」 -> 「Base Line Position」 : Left: 

























		Center:  Right: 
D	 Display & Setting of Max Speed	Display the Max speed. Press it to have access to the setting interface of speed.◦
E	 Display & Setting of Normal Feeding	Display the normal feeding value. Press it to have access to the setting interface of the normal feeding
F	 Display and Setting of Compensation	Display the compensation value. Press it to have access to the interface for setting the compensation value.
G	 Display & Setting of Start Point	Display the position of the start point. Press it to have access to the interface for setting the start point.  : Right  : Left 1  : Left 2  : Random
H	 Display & Setting of End Point	Display the position of the end point. Press it to have access to the interface for setting the end point.  : Right  : Left 1  : Left 2  : Random
I	-	Refer to the description in Line Setting

### 3.6.7 Set Pattern 1(单步进没有此花样)




#### Functions:








A	Current Pattern	Display the current pattern. Press it to return to the shape selection interface.
B	 Display and Setting of Swing Width	Display the swing width. Press it to have access to the interface for setting the swing width.
C	 Display and Setting of Base Line	Display the position of the base line. Press it to have access to the interface for setting the base line The figure displayed can be changed via 「General Parameter」 -> 「Base Line Position」 : Left:  Center:  Right: 
D	 Display & Setting of Max Speed	Display the Max speed. Press it to have access to the setting interface of speed.。
E	 Display & Setting of	Display the normal feeding value. Press it to have access to the setting interface of the normal feeding


















	Normal Feeding	
F	 Display and Setting of Compensation	Display the compensation value. Press it to have access to the interface for setting the compensation value.
G	 Display & Setting of Start Point	Display the position of the start point. Press it to have access to the interface for setting the start point.   : Center 1  : Center 2  : Left  : Center 3  : Right  : Random
H	 Display & Setting of End Point	Display the position of the end point. Press it to have access to the interface for setting the end point.   : Center 1  : Center 2  : Left  : Center 3  : Right  : Random
I	-	Refer to the description in Line Setting

### 3.6.8 Set Pattern 2(单步进没有此花样)




#### Functions:








A	Current Pattern	Display the current pattern. Press it to return to the shape selection interface.
B	 Display and Setting of Swing Width	Display the swing width. Press it to have access to the interface for setting the swing width.
C	 Display and Setting of Base Line	Display the position of the base line. Press it to have access to the interface for setting the base line The figure displayed can be changed via 「General Parameter」 -> 「Base Line Position」 : Left:  Center:  Right: 
D	 Display & Setting of Max Speed	Display the Max speed. Press it to have access to the setting interface of speed.
E	 Display & Setting of Normal Feeding	Display the normal feeding value. Press it to have access to the setting interface of the normal feeding


















F	 Display & Setting of Contrary Feeding	Display the contrary feeding value. Press it to have access to the setting interface of the contrary feeding
G	 Display & Setting of Start Point	Display the position of the start point. Press it to have access to the interface for setting the start point.   : Right 1  : Center 1  : Left 1  : Left 2  : Center 2  : Right 2  : Random
H	 Display & Setting of End Point	Display the position of the end point. Press it to have access to the interface for setting the end point.   : Right 1  : Center 1  : Left 1  : Left 2  : Center 2  : Right 2  : Random
I	-	Refer to the description in Line Setting

### 3.6.9 Set Pattern 3(单步进没有此花样)




#### Functions:








A	Current Pattern	Display the current pattern. Press it to return to the shape selection interface.
B	 Display and Setting of Swing Width	Display the swing width. Press it to have access to the interface for setting the swing width.
C	 Display and Setting of Base Line	Display the position of the base line. Press it to have access to the interface for setting the base line The figure displayed can be changed via 「General Parameter」 -> 「Base Line Position」 : Left:  Center:  Right: 
D	 Display & Setting of Max Speed	Display the Max speed. Press it to have access to the setting interface of speed.
E	 Display & Setting of Normal Feeding	Display the normal feeding value. Press it to have access to the setting interface of the normal feeding

F	 Display & Setting of Contrary Feeding	Display the contrary feeding value. Press it to have access to the setting interface of the contrary feeding
G	 Display & Setting of Start Point	Display the position of the start point. Press it to have access to the interface for setting the start point.   : Right 1  : Center 1  : Left 1  : Left 2  : Center 2  : Right 2  : Random
H	 Display & Setting of End Point	Display the position of the end point. Press it to have access to the interface for setting the end point.   : Right 1  : Center 1  : Left 1  : Left 2  : Center 2  : Right 2  : Random
I	-	Refer to the description in Line Setting


















### 3.6.10 Set Pattern 4(单步进没有此花样)



#### Functions:

A	Current Pattern	Display the current pattern. Press it to return to the shape selection interface.
B	 Display and Setting of Swing Width	Display the swing width. Press it to have access to the interface for setting the swing width.
C	 Display and Setting of Base Line	Display the position of the base line. Press it to have access to the interface for setting the base line The figure displayed can be changed via 「General Parameter」 -> 「Base Line Position」 : Left:  Center:  Right: 
D	 Display & Setting of Max Speed	Display the Max speed. Press it to have access to the setting interface of speed.。
E	 Display & Setting of Normal Feeding	Display the normal feeding value. Press it to have access to the setting interface of the normal feeding




F	 Display & Setting of Contrary Feeding	Display the contrary feeding value. Press it to have access to the setting interface of the contrary feeding
G	 Display & Setting of Start Point	Display the position of the start point. Press it to have access to the interface for setting the start point.   : Left 1  : Left 2  : Right 1  : Right 2  : Right 3  : Left 3  : Random
H	 Display & Setting of End Point	Display the position of the end point. Press it to have access to the interface for setting the end point.   : Left 1  : Left 2  : Right 1  : Right 2  : Right 3  : Left 3  : Random
I	-	Refer to the description in Line Setting

### 3.7 Customized Pattern






- The customized pattern is the pattern with free needle entry position that user can edit it at will.
- The customized pattern can created at the operation panel or imported from outside.
- At most 500 customized patterns can be saved, and each pattern can contain 500 stitches.



### 3.7.1 Set Customized Pattern

According to the content in [3.5.2 Customized Pattern Selection], user can have access to the interface for setting customized pattern.





#### Functions:


A	Pattern Number	Display the current pattern number. Press it to have access to the interface for selecting the customized pattern.
B	 Edition	Press it to have access to pattern edition interface
C	 Display & Setting of Max Speed	Display the Max speed. Press it to have access to the setting interface of speed.。
D	Pattern Display	Display the shape of the current pattern
E	 Display and Setting of Swing Width	Display the swing width. Press it to have access to the interface for setting the swing width.
F	 Display and Setting of Base Line	Display the position of the base line. Press it to have access to the interface for setting the base line The figure displayed can be changed via 「General Parameter」 -> 「Base Line Position」 : Left: 

		Center:  Right: 
G	-	Refer to the description at the setting of basic pattern. (双步进款独有)

### 3.7.2 Create the Customized Pattern

Refer to the content in [3.5.2 Customized Pattern Selection], user can press **New** to have access to the interface for creating the customised pattern.

- 1、 The Number Area (A) will display the empty number for saving, and user can set it with Keyboard (B).
- 2、 After the number is set, user can press  to finish the operation and enter the edition interface of the customized pattern or press  to cancel the operation and return to the previous interface






**[Note] If the inputted number has existed, the system will hint “Pattern Number Exists”**

### 3.7.3 Copy Customized Pattern

According to the content in [3.5.2 Customized Pattern Selection], user needs select the pattern for copy and press **Copy** to have access to the interface for copying the customized pattern.


Its operation method is same as that in creating the customized pattern. Press


 to quit, while press  to confirm the operation and to return to the interface for selecting the customized pattern.





**[Note] If the inputted number has existed, the system will hint user “Replace the Pattern in Memory?”**





### 3.7.4 Edit the Customized Pattern

After creating the customized pattern, user needs activate the edition interface or press  in the customized pattern setting interface. After the operation, the system will enter the interface for setting the customized pattern.



### Functions

A	Pattern Number	Display the number of customized pattern
B	Pattern Display	Display the stitch form on pattern and the position of icon
C	Display and Setting of Stitch Number	Display the needle number that is in edition status at present. Press  and  to adjust the needle number. At same time, the icon in pattern display area will move along with


		the setting.
D	Display and Setting of Swing Width	Display the needle swing width of the current stitch. That value stands for the X absolute coordinate. Press  or  to adjust the value, the range of it is -5.0~5.0mm.
E	Display and Setting of Feeding Amount	Display the feeding amount of the current stitch. That value stands for the Y relevant coordinates Press  or  to adjust the value, the range of it is -5.0~5.0mm.
F	Insert a Stitch	Insert a stitch at the current stitch. The inserted stitch has the same swing width as the current stitch. And system will add 1.0mm to the feeding amount. <b>[Note]: when the total stitch number is 500, this operation is unavailable.</b>
G	Delete a Stitch	Delete the needle entry point of current stitch, and the following stitches will move forwards. <b>[Note]: when the total stitch number is 1, this operation is unavailable.</b>
H	End Mark	Input the end mark. Once you input the end mark at the current stitch, the stitches after the current stitch will become invalid.
I	Cancel	Cancel the current operation and return to the previous level
J	Enter	Confirm the operation and save the editing result. The system will enter the interface for setting the editing pattern

## 3.8 Saved Pattern

- After the registration, the basic patterns or the customized patterns will become the saved pattern. User can only register the pattern in free sewing mode and overlapped sewing mode.
- After the registration: user can not edit the data of the saved pattern from the customized pattern, while he can edit the parameters of the saved pattern from the basic pattern.


### 3.8.1 Set the Saved Pattern

According to the contents in [3.5.3 Selection of the Saved Pattern], user can have access to the interface for setting the saved pattern.



The saved pattern registered from the basic pattern

【注】单步进没有  和  设置。



The saved pattern registered from the customized pattern

**Functions:**

A	Pattern Number	Display the pattern number. Press it to have access to the interface for selecting the saved pattern.
B	Pattern Shape at Registration	Display the shape of pattern at registration.

C	Display & Setting of Max Speed	Display the Max speed. Press it to have access to the setting interface of speed.
D	Pattern Parameter	Display the parameters corresponding to the registered shape at present. For the setting method and the displayed content, please refer to the relating section in basic pattern and customized pattern.
E	-	Refer to the description in basic pattern setting
F	Copy	Press it to have access to the interface of pattern copy


### 3.8.2 Register Pattern

We use the 2-points zigzag sewing as example:

#### 1、 Select Pattern for Registration


Set the pattern for registration and its sewing mode and reverse sewing. Then, have access to the interface for setting


the pattern. Press  to enter the pattern registration interface.




#### 2、 Input Registration Number

In number display area (A), the system will give the empty number for saving, user can also input the number via the keyboard (B)

Press  to cancel the operation and return to the previous level interface,


press  to finish the operation



[Note] If the inputted number has existed, the system will hint user “Replace the Pattern in Memory?”


### 3、 End Registration


After the successful registration, the system will enter the pattern setting interface, where the registered pattern will become the current sewing pattern.



## 3.8.3 Copy the Saved Pattern



### 1 、 Have Access to Pattern Copy Interface


In the interface for setting the saved pattern, press  to have access to the pattern copy interface.



### 2、 Copy Pattern

The number display area (A) will display the empty number for copy; user can use the keyboard (B) to input the number to copy.

Press  to cancel the operation;  
 Press  to finish the operation and return to the interface for setting the saved patterns




[Note] If the inputted number has existed, the system will hint user “Replace the Pattern in Memory?”



### 3.9 Continuous Sewing

- The continuous sewing is formed by one or more saved patterns. The continuous sewing can contain 32 steps at most, and user can set at most 500 stitches in each step.
- The continuous sewing is sewn as one pattern.


#### Example:



- 1、 As the left picture shows, user can register the 2-points zigzag sewing as pattern 1, 3-points zigzag sewing as pattern 2 and 4-points zigzag sewing as pattern 3.


- 2、 Design the stitch number as below:

Step	Pattern No.	Stitch Number
1	2	4
2	1	4
3	3	4


- 3、 Press  in edition interface to finish the operation.

#### 3.9.1 Set Continuous Sewing

According to the content in [3.5.4 Continuous Sewing Selection], user can have access to the interface for setting the continuous sewing.






## Functions:

A	Pattern Number	Display the pattern number. Press it to have access to the interface for selecting the continuous sewing pattern.
B	Steps of Continuous Sewing	Display the continuous sewing steps. Use  to shift the registration information of steps in the continuous sewing
C	Edition	Press it to have access to the interface for editing the continuous sewing.
D	Quoted Number	Display the number of saved pattern quoted in the current step.
E	Step Stitch Number	Display the stitch number at current step.
F	Display and Setting of Swing Width	Display the swing width. Press it to have access to the interface for setting the swing width.
G	Display and Setting of Base Line	Display the position of the base line. Press it to have access to the interface for setting the base line
H	Reverse Sewing Setting	Please refer to the description in basic pattern section

### 3.9.2 Create Continuous Sewing


According to the content in [3.5.4 Continuous Sewing Selection], user can press **New** to enter the interface for creating the continuous sewing.



- The number display area (A) will display the empty number for saving; user can use the keyboard (B) to input the number wanted
- After confirming the number, user can press  to finish the operation and enter the continuous sewing edition interface. Press  to cancel the operation and return to the previous interface




**[Note] If the inputted number has existed, the system will hint “Pattern Number Exists”**

### 3.9.3 Copy Continuous Sewing


According to the contents in [3.5.4 Continuous Sewing Selection], user can select the pattern for copy and press  to have access to the continuous sewing copy interface.


The operation is same as that in the creation of continuous sewing. Press  to cancel the operation, press  to confirm the operation and return to the continuous sewing selection interface.



[Note] If the inputted number has existed, the system will hint user “Replace the Pattern in Memory?”

### 3.9.4 Edit Continuous Sewing

After creation of the continuous sewing, the system will enter the edition interface; or user can press  in continuous sewing setting interface to enter the edition interface.






## Functions:

A	Pattern Number	Display the number of the continuous sewing
B	Quoted Number	Display the number of saved pattern quoted in the current step.
C	Stitch Number of Step	Display the stitch number in current step.
D	Page Number	Display the current page/ total pages
E	Cancel	Cancel the operation and quit
F	Page Key	Turn the page.
G	Load Pattern	Press it to have access to the selection interface of quoted patterns. It is used to set the quoted pattern and its stitch number in current step.
H	Step Deletion	Delete the selected step. The steps following will move forward.
I	Clear	Clear the entire content in the continuous sewing
J	Enter	Confirm the operation and quit


## Operation:

### 1、 Edit Current Step

Press  to enter the interface for selecting the quoted pattern and select the saved pattern for adding. We select No.8 ptttern and set the stitch number of the current step at 10. Press  to confirm the selection.





**[Note]: the step edition shall be done in order**




### 2、 Continue Editing Steps


Repeat the operation at above to add new quoted patterns (Here, we added No.5, No.1 and No.10 pattern in order).

If user wants to delete a quoted pattern, he should click its number and press .



### 3、 Save Continuous Sewing

Press  to confirm the saving and return to the setting interface of continuous sewing.




## 3.10 Cyclic Sewing

- The cyclic sewing is formed by one or more saved patterns. It can contain 32 steps at most, in which the machine will sew the different patterns.
- The cyclic sewing can be deemed as the machine performs several program sewing according to the set stitch numbers.

### Example:

After user sets the stitch number at cyclic sewing, the pattern in each step can be sewn in different length.



1、 Register the 2-points zigzag sewing to pattern 1 and register the line to pattern 2


2、 Set the stitch number as shown in table below:

Steps	Pattern No.	Stitch Number
1	1	100
2	2	50
3	1	100
4	2	50



3、 In edition interface, press  to finish the operation.

### 3.10.1 Set Cyclic Sewing

According to the contents in [3.5.5 Cyclic Sewing Selection], user can have access to the interface for setting the cyclic sewing.




#### Functions:

A	Pattern Number	Display the current pattern number. Press it to have access to the cyclic sewing selection interface.
B	Cyclic Sewing Step	Display the cyclic sewing step. Use  or  to shift the cyclic sewing steps
C	Edition	Press it to have access to the interface for editing the cyclic sewing.
D	Quoted Pattern Display	Display the pattern quoted at current step.

E	Reverse Sewing Setting	Refer to the description at Basic Pattern
F	Quoted Number	Display the number of saved pattern quoted in the current step.
G	Sewing Method	Display the current sewing method


**[Note]: If the sewing mode of the pattern quoted in current step is free sewing or overlapped sewing, the system will not display the stitch number, stop status, presser stop position and presser up time as below:**




### 3.10.2 Create Cyclic Sewing


According to the contents in [3.5.5 Cyclic Sewing Selection], user can press **New** to enter the interface for creating the cyclic sewing.

1、The number display area (A) will display the empty number for saving; user can use the keyboard (B) to input the number wanted as well

2、After setting the number, user can press  to finish the operation and enter the cyclic sewing edition interface;


Press  to cancel the operation and return to the previous screen



**[Note] If the inputted number has existed, the system will hint “Pattern Number Exists”**




### 3.10.3 Copy Cyclic Sewing

According to the contents in [3.5.5 Cyclic Sewing Selection], user can select the pattern for

copy and press  to have access to the cyclic sewing copy interface.


The operation is same as that in the creation of cyclic sewing. Press  to cancel the operation; press  to confirm the operation and return to the cyclic sewing selection interface.




**[Note] If the inputted number has existed, the system will hint user “ Replace the Pattern in Memory?”**

### 3.10.4 Edit Cyclic Sewing






After creation of the cyclic sewing, the system will enter the edition interface; or user can

press  in cyclic sewing setting interface to enter the edition interface.






**Functions:**

A	Cyclic Sewing Number	Display the cyclic sewing number.
B	Step	Display the current step
C	Single Sewing	Set whether the current step is single sewing. <b>[Note 1]: If the current step is free sewing, the current step can not be set as single sewing.</b> <b>[Note 2]: If the current step is overlapped sewing, the current step can only be the single sewing.</b>
D	Quoted Pattern Number	Display the number of pattern quoted at current step. Press it to enter the interface for selecting the quoted pattern.
E	Current Step Sewing Mode	Display the sewing mode at current step. Press it to turn to the free sewing switch. <b>[Note]: It can not be set when the current step is overlapped sewing</b>
F	Stitch Number Setting	Set the stitch number at current step; Range: 1~500 stitches <b>[Note] It can not be set when the current step is overlapped sewing or free sewing</b>
G	Stop Status	Set the stop status of current step  : Needle Down Stop  : Trimming  : Needle Up Stop <b>[Note] It can not be set when the current step is overlapped sewing or free sewing</b>
H	Presser Position	Set the presser position of current step  : Presser Down Stop  : Presser Up Stop <b>[Note] It can not be set when the current step is overlapped sewing or free sewing</b>
I	Presser Up Time	Set the presser up time at current step. Range:0.1~99.9s
J	Cancel	Press it to cancel the operation and quit
K	Enter	Press it to save the settings and enter the interface for setting the cyclic sewing.
L	Step Deletion	Delete the current step

**Operation:**

### 1、 Edit Current Step


Enter the edition interface of cyclic sewing. Adjust A to select the current step and check the information. In this example, all the steps are empty, so user has to start the edition from step 1.



### 2、 Select the Quoted Pattern

Press button (B) to enter the interface for selecting the quoted pattern, where user can select the saved pattern or the continuous sewing for adding. Here, we select No.1 pattern,


please press  to confirm it.




### 3、 Set Step Parameter

After the pattern selection, user can use C to check the sewing mode of current step. The default setting to use the original sewing mode of the quoted pattern. In this example, the No.1 saved pattern is the free sewing.


Press button C to turn off the free sewing, and set the stitch number at 20, as well as the parameters like stop status, presser position, presser up times and so on.







#### 4、 Continue Editing Step

Set the current step as 2. Repeat the operations at above and add more quoted patterns.




#### 5、 Save Cyclic Sewing

Press  to confirm saving and enter interface for setting cyclic sewing.



### 3.11 Sewing Mode Setting

- According to the contents in [3.4 Main Interface] and [3.6.1 Setting of Line], user can use  or press sewing mode button at pattern setting interface to enter the setting interface of sewing mode.
- The sewing mode contains free sewing, overlapped sewing and program sewing.




**Functions:**


A	Free Sewing	Press it to select free sewing mode
B	Overlapped Sewing	Press it to select overlapped sewing mode.
C	Program Sewing	Press it to select program sewing mode
D	Current Pattern	Display the shape of current pattern

**3.11.1 Overlapped Sewing**

- In overlapped sewing, the system will open the auto trimming and single sewing as default.



**Functions:**


A	Display & Setting of Stitch Number in Steps A, B and C	Respectively display the stitch number in step A, B and C. Press the setting button to enter the setting interface of overlapped sewing. Range: 0~19 stitches
B	Display & Setting of Step D	Display the total step number of A, B and C. Press the setting key to enter the overlapped sewing setting interface. Range: 0~9. 

**Operation:**

Press A, B, C or D to enter the overlapped sewing setting interface.


At here, we set the stitch number of step A, B and C at 4 respectively. The total step number (D) at 5. Therefore the system will perform the step A for once, step B for twice and step C for twice. After the setting, user

can press  to save and quit.



**3.11.2 Program Sewing**


- In program sewing, user can set 20 steps at most, and each step can contain 500 stitches at most.
- In the program sewing, if one step is set as thread-trimming or its stitch number is set at 0, the following steps will be canceled.





**Functions:**

A	Step Information	Display the stitch number of each step in the program sewing. Press it to enter the setting interface of program sewing.
B	Page Key	Press it to turn the pages [Note]: Only display when the step number is over 10.

**Set Program Sewing:**





Example: Press  to enter the setting interface of program sewing.







No.	Descriptions
A	Display current step. Pressing the arrows in  will change the current step. If the current step is the last one, pressing the right arrow will add a new step. At most 20 steps can be set. <b>[Note]: If needing to add new step, user should set the auto trimming in current step as Ineffective.</b>
B	Display stitch number in current step.
C	Input the stitch number in current step.
D	Set auto trimming. <b>[Note] The step set with the auto trimming will become the last step.</b>
E	Set single sewing. Select it to set the single sewing. After user sets the single sewing, the system will automatically sew to the stitch number of that step.
F	Cancel the setting and quit.
G	After all the steps are set, the system will save the setting the quit.

### 3.12 Set


## Reverse Sewing


- Reverse Sewing is used for strengthening the parts at sewing start and sewing end. It contains standard reverse sewing, 2-points contraction sewing and customized reverse sewing
- Pressing front reverse sewing switch (  or  ) and back reverse sewing switch (  or  ) can activate or deactivate the reverse sewing.

Front reverse sewing	Ineffective	Effective	Ineffective	Effective
Pattern				
Back reverse sewing	Ineffective	Ineffective	Effective	Effective


### Setting Method:

### 1、 Enter Setting Interface of Reverse Sewing

Press  to enter the interface for setting the reverse sewing. At here, we use the standard front reverse sewing as the example: Pressing the front reverse sewing type key to enter the interface for setting the front reverse sewing.




### 2、 Select Reverse Sewing Type

As shown in the picture, after user select the sewing type, user needs press  to back to the reverse sewing setting interface.





### 3、 Set Reverse Sewing Parameters

In the reverse sewing setting interface, user can press step button A or B to enter the parameter setting interface



### 4、 Input the Stitch Number in Step

As the picture shows, press the arrows to input the stitch number in steps. press  to return to the reverse sewing setting interface















### 3.12.1 Standard Reverse Sewing

- At the standard reverse sewing, user can perform the reverse sewing with the needle entry points same to the current pattern.

#### Example:



## Functions:

A	Current Pattern	Display the shape of the current pattern
B	Front Reverse Sewing Switch	Turn-on/off the front reverse sewing  : Effective  : Ineffective
C	Front Reverse Sewing Type	Display the type of the front reverse sewing. Press it to enter the selection interface of front reverse sewing type.  : Standard Front Reverse Sewing
D	Front Reverse Sewing Step A & B	Display the stitch number of front reverse sewing A & B. Press the Set button to enter the interface for setting front reverse sewing parameters.
E	Back Reverse Sewing Switch	Turn-on/off the back reverse sewing  : Effective  : Ineffective
F	Back Reverse Sewing Type	Display the type of the back reverse sewing. Press it to enter the selection interface of back reverse sewing type  : Standard Back Reverse Sewing
G	Back Reverse Sewing Step C & D	Display the stitch number of back reverse sewing C & D. Press the Set button to enter the interface for setting back reverse sewing parameters.
H	Display & Setting of Cloth-feeding	Display the cloth-feeding amount. Press it to have access to the interface for setting the cloth-feeding amount. <b>[Note]: Only when the current pattern is the customized pattern, can the system display this item</b>

According to the difference of the pattern, there are two ways for setting the reverse sewing:

1) At the line, scallop, blind stitch, customized pattern and continuous sewing, user can use the stitch number to set it.

Front reverse sewing → A (feeding in positive direction): Can set 0~19 stitches.

B (feeding in opposite direction): Can set 0~19 stitches.

Back reverse sewing → C (feeding in opposite direction): Can set 0~19 stitches.


D (feeding in positive direction): Can set 0~19 stitches.

2) At 2-points zigzag, 3-point zigzag and 4-points zigzag, user can use the times of the needle swing pattern, which is the pattern part between the return points

Front reverse sewing → A (feeding in positive direction): can set 0~19 times



B (feeding in opposite direction): can set 0~19 times

Back reverse sewing->C (feeding in opposite direction): can set 0~19 times  
 D (feeding in positive direction): can set 0~19 times





### 3.12.2 2-points Contraction Sewing

- With the 2-points contraction sewing function, user can make the reverse sewing between the current needle entry point and the next needle entry point.
- The width between two point can be adjusted in “-” direction.




## Functions:

A	Current Pattern	Display the shape of the current pattern
B	Front Reverse Sewing Switch	Please refer to description in standard reverse sewing
C	Front Reverse Sewing Type	Display the type of the front reverse sewing. Press it to enter the selection interface of front reverse sewing type  : 2-points contraction sewing (Front)
D	Front Reverse Sewing Step A & B	Please refer to description in standard reverse sewing
E	Front Reverse Sewing Contraction Distance	Display the contraction distance of Front Reverse Sewing. Press the button to enter the interface for setting front reverse sewing parameters.
F	Back Reverse Sewing Switch	Please refer to description in standard reverse sewing
G	Back Reverse Sewing Type	Display the type of the back reverse sewing. Press it to enter the selection interface of back reverse sewing type  : 2-points contraction sewing (Back)
H	Back Reverse Sewing Step C & D	Please refer to description in standard reverse sewing
I	Back Reverse Sewing Contraction Distance	Display the contraction distance of Back Reverse Sewing. Press the button to enter the interface for setting back reverse sewing parameters.

## Description of Setting Contraction Distance:


Example: how to set the 2-points contraction distance of the front reverse sewing

The width adjustment can narrow the distance from the original needle entry point to the next needle entry point at reverse sewing (no adjustment when the value is 0)



### 3.12.3 Customized Reverse Sewing

- This enable user to perform reverse sewing at any inputted needle entry point.
- At most, 64 stitches can be supported.





#### Functions:

A	Current Pattern	Display the shape of the current pattern
B	Front Reverse Sewing Switch	Please refer to description in standard reverse sewing
C	Number of Customized Pattern in Front Reverse Sewing	Display the number of the customized pattern in the front reverse sewing. Press it to enter the interface for selecting the customized pattern in the front reverse sewing.
D	Customized Pattern in Front Reverse Sewing	Display the shape of the customized pattern in front reserve sewing
E	Front Reverse Sewing Width	Display the sewing width of the front reverse sewing. Press the button to enter the interface for setting front reverse sewing parameters
F	Edition of Front Reverse Sewing	Press the button to enter the interface for editing the customized pattern in front reverse sewing
G	Back Reverse Sewing Switch	Please refer to description in standard reverse sewing
H	Number of Customized Pattern in Back Reverse Sewing	Display the number of the customized pattern in the back reverse sewing. Press it to enter the interface for selecting the customized pattern in the back reverse sewing.
I	Customized Pattern in Back Reverse Sewing	Display the shape of the customized pattern in back reserve sewing
J	Back Reverse Sewing Width	Display the sewing width of the back reverse sewing. Press the button to enter the interface for setting back reverse sewing parameters
K	Edition of Back Reverse Sewing	Press the button to enter the interface for editing the

	customized pattern in back reverse sewing
--	---

### 1) Set Swing Width of Customized Reverse Sewing Pattern:


Example: how to set the swing width of the customized pattern in front reverse sewing.


In the interface for setting the reverse sewing, press  to have access to the interface for setting the reverse sewing parameters, as shown in right picture. Adjust the arrow to set the swing width. Press  to return to the reverse sewing setting interface.





[Note]: please set it within the Max swing range

### 2) Select Customized Reverse Sewing Pattern:


We take the front reverse sewing as the example. Press  to have access to the interface for selecting the customized reverse sewing pattern.





### Functions:


No.	Functions	Contents
A	Pattern Display Area	Display the shape of the selected pattern
B	Pattern Selection Area	Display the number of customized reverses sewing pattern in operation panel
C	Standard Reverse Sewing	Shift the type to standard reverse sewing
D	2-points Contraction Sewing	Shift the type to 2-points contraction sewing
E	Customized Reverse Sewing	Press it to enter the selection interface of customized reverse sewing
F	Cancel	Cancel the current operation and quit
G	New Pattern	Create a new customized reverses sewing
H	Single Selection/ Multi-selection	Shift between single selection and multi-selection. In multi-selection, user can selection several customized reverse sewing at same time, which can be used for deleting patterns.  : Single Selection  : Multi-selection
I	Select All	Select all the customized reverse sewing patterns. It can be used in the operation of deletion
J	Deletion	Delete the selected pattern.
J	Enter	Confirm the selection of the current pattern and enter the reverse sewing setting interface. <b>[Note] The Enter can only be used in single selection status</b>

### 3) Create the Customized Reverse Sewing Pattern:

Referring to the contents in above sector, user can press  to enter the interface for creating the customized reverse sewing pattern.


- The number display area (A) will display the empty number for saving; user can use the keyboard (B) to input the number wanted as well.
- After confirming the number, user can press  to finish the operation and return or press  to cancel the operation and return.

**[Note] Can not use the existing number.**



### 4) Edit the Customized Reverse Sewing Pattern:









After creation of the customized reverse sewing, the system will enter the edition interface; or user

can press  in reverse sewing setting interface to enter the edition interface.

For the operation methods, please refer to [3.7.4 Edit the Customized Pattern]. The max permitted stitch number for the customized sewing is 64 stitches




### 3.12.4 Comparison of Reverse Sewing Patterns

	Standard Reverse Sewing		2-points Contraction Sewing		Customized Reverse Sewing	
	Front Reverse Sewing	Back Reverse Sewing	Front Reverse Sewing	Back Reverse Sewing	Front Reverse Sewing	Back Reverse Sewing
Line						
Other patterns						

### 3.13 Information Mode

In the main interfaces, press  to enter information mode.






**Functions:**

No.	Functions	Contents
A	Parameter Setting	Enter parameter setting interface
B	Parameter Management	Provide the functions of parameter transfer, parameter restoration and parameter encryption
C	Counters	Set the thread-trimming counter and the bottom thread counter
D	Display Setting	The settings of display, such as back light, keyboard lock and screen protect and so on.
E	Version Inquiry	Inquire the version of system software
F	Test	Enter the system test interface
G	Data Transfer	Transfer the patterns between the operation panel and the U disk
H	Alarm Record	Check the alarm statistic information.
I	Working Record	Check the running information of machine
J	Format	Formatting the U disk and pattern
K	Date and Time	Set date and time
L	Password Mode	Activate the periodical password for user
M	Software Update	Enter software update mode
N	Display Shift	Shift the display between the Text and Figure
O	ESC	Return to main interface

In the information mode, the system supports two display styles: Figure and Text  
 This is the text style:





### 3.13.1 Parameter Setting

The parameter setting is used to set the parameters. for the description of each parameter, please refer to [3.13.4 Parameter List].

#### Setting Method:


##### 1、 Enter Parameter Setting:

In main interface, press  to enter the information mode, as shown in right. And then press .



##### 2、 Parameter Setting Interface

In the parameter setting interface, there are many parameters for selection. User can use






### 3、 Examples:


#### ① Select Parameter Type

The parameters are divided in types. We select “Main-shaft and Speed”.





#### ② Interface for Setting the Internal Parameters

Enter the interface for setting the internal parameters. We can see the information of all the parameters in the current group. Here, we press 「P3-4」 .





#### ③ Change the Parameter Value

Use the number keyboard to input the new value and then press  to confirm.




#### ④ Check the Parameter Value after Change

Return to the interface for setting the internal parameters and check the value after the change. Press  to quit.



#### ⑤ Return to Interface for Selecting Parameter Type

Return to the interface for selecting the parameter type. Because the original value is changed, the Changed Parameter will be displayed

Press  to back to information mode interface.

To check the content of the changed parameter, please press “Changed Parameter”

#### ⑥ Check the Content of Changed Parameter

##### a) Enter Password Input Mode

Press “Changed Parameter” to enter the password input mode. Input the right parameter to enter the changed parameter setting mode (For setting password, please refer to [3.13.5 Parameter Encryption])




**b) Enter the Setting Mode of Changed Parameter**

In this interface, the system will display the changed content of the parameter. If user needs change the value again, he can change it again


If user wants to restore the changed parameter, please press that parameter (at here, user can press Swing Limits or Sewing Speed at One Time) and “Restore”, then follow the hint to operate the machine.

If user wants to restore all the changed parameters, please press “Restore All” and then follow the hint to operate the machine.




**Instruction of Parameter Setting Classification:**

The setting of the parameters contains two types, one is the input type, the other is the input type, as shown at below:



Selection Type



Input Types

[Note] Pressing  will display the detailed description on that parameter.

**3.13.2Parameter List**

**1、 General Parameters:**

Code	Brief	Description	Unit	Step Length	Range	Default Value	Type
P1-0	Swing Type	Set the swing method in system			0:CEN:Center Symmetry 1:LR:LR Symmetry	0	Selection
P1-1	Center	The swing range at center	mm	0.1	0~10.0	10.0	Input

	Symmetry Swing Limits	symmetry					
P1-2	Swing Left Limits (LR Swing)	Set down left limits in LR Swing method	mm	0.1	-5.0~0	-4.0	Input
P1-3	Swing Right Limits (LR Swing)	Set down right limits in LR Swing method	mm	0.1	0~5.0	4.0	Input
P1-4	Base Line Position	Base line position setting			0:CEN:Center 1:L:Left 2:R:Right	0	Selection
P1-5	Contrary Feeding Limits	Set the contract feeding limits	mm	0.1	-5.0~5.0	-5.0	Input
P1-6	Normal Feeding Limits	Set the normal feeding limits	mm	0.1	-5.0~5.0	5.0	Input
P1-7	Symmetry Function Setting	Set the symmetry function			0:SIG:Single Pattern Symmetric Inversion 1:CON: Continuous Symmetric Inversion	0	Selection
P1-8	Base Line Position of Customized Reverse Sewing	Set the base line position of customized reverse sewing			0:COM: Linkage 1:FIX:Fixed	0	Selection
P1-9	Swing Limits Display	Display the setting on Swing limits at power-on.			0:ON: Display 1:OFF: Not Display	0	Selection

【注】P1-5 和 P1-6 是单步进没有。

## 2、Reverse Sewing

Code	Brief	Description	Unit	Step Length	Range	Default Value	Type
P2-0*	Midway Reverse Sewing	Set the reverse sewing function in midway			0:OFF:No 1:ON:Yes	ON	Selection
P2-1*	Midway Reverse Sewing Stitch Number	Set the reverse sewing stitch number in midway		1	0~19	4	Input
P2-2	Midway Reverse Sewing Setting at Stop	Midway reverse sewing setting at stop			0:OFF: Ineffective at Machine Stop 1:ON: Effective at Machine Stop	ON	Selection
P2-3*	Stop Function at	Set the stop function at			0:OFF:No	0	Selection

	Starting the Reverse Sewing	starting the reverse sewing.			1:ON:Yes		
P2-4	Deceleration Function at Reverse Sewing Start	Decelerating function at reverse sewing start			0:OFF:Not Decelerate 1:ON: Decelerate	0	Selection
P2-5*	Reverse Sewing Holding Time	Set the holding time of the reverse sewing solenoid	s	1	2~250	60	Input
P2-6*	Reverse Sewing Total Pressure Output Time	Set the total pressure control time of the reverse solenoid	ms	1	50~250	100	Input
P2-7*	Reverse Sewing Output Duty Cycle	Set the current when the reverse solenoid is holding		1	0~100	40	Input

\*The parameters with mark “\*” should be changed under the guide of the professional technicians.

### 3、Main-shaft and Speed:

Code	Brief	Description	Unit	Step Length	Range	Default Value	Type
P3-0	Soft Start Stitch Number	Set the stitch number of soft start at sewing	Stitch	1	0~9	3	Input
P3-1*	Soft Start Speed	Set the speed at soft start	rpm	50	150~5000	1200	Input
P3-2*	Reverse Sewing Speed	Set the Max speed at reverse sewing	rpm	50	150~3000	1500	Input
P3-3	Min Speed	The Min Speed	rpm	10	20~400	200	Input
P3-4	Sewing Speed at One Time	Set the speed at an automatic sewing	rpm	50	200~5000	3000	Input
P3-5*	Down Needle Stop Angle	Down Needle Stop Angle	Degree	10	120~200	160	Input
P3-6	Needle Conversion at Trimming	Set the function for converting the needle after trimming			0:OFF: No 1:ON:Yes	0	Selection
P3-7	Conversion Needle Angle	Set the angle for converting the needle	Degree	1	0~45	20	Input
P3-8*	Return at Power-on	Set needle return to the previous position at power-on			0:OFF: No 1:ON:Yes	0	Selection

\*The parameters with mark “\*” should be changed under the guide of the professional technicians.

### 4、Thread-trimming:

Code	Brief	Description	Unit	Step Length	Range	Default Value	Type
P4-0	Trimming Function	Set the trimming function			0:OFF:Ineffective 1:ON:Effective	1	Selection
P4-1*	Trimming Speed	Set the speed at trimming	rpm	10	20~300	300	Input

P4-2	Midway Reverse Sewing Trim	Set whether to trim thread automatically at reverse sewing			0:OFF:Ineffective 1:ON:Effective	0	Selection
P4-3*	Trimming Angle Adjustment	Adjust the thread-trimming angle		1	-30~30	0	
P4-4*	Thread-stirring Time	The holding time for stirring thread	ms	1	0~250	70	Input

\*The parameters with mark “\*” should be changed under the guide of the professional technicians.

## 5、Presser and Pedal:

Code	Brief	Description	Unit	Step Length	Range	Default Value	Type
P5-0*	Presser Control Method	Select the device control the action of presser			0:MAG:Solenoid 1:AIR:Valve 2:MEC:Mechanism (No presser auto up function)	0	Selection
P5-1	Presser Up at Pedal in Middle	Lift presser when pedal at middle position			0:OFF:Ineffective 1:ON:Effective	0	Input
P5-2	Auto Lift Presser	Activate the presser auto up function			0:OFF:Ineffective 1:ON:Effective	1	Input
P5-3*	Pedal Stroke at Start	Pedal stroke at sewing start		1	10~50	30	Input
P5-4*	Pedal Stroke at Accelerating	Pedal stroke at starting acceleration		1	10~100	60	Input
P5-5*	Pedal Stroke at Presser Down	Pedal stroke at presser down		1	-60~-10	-21	Input
P5-6*	Pedal Stroke at Presser Up	Pedal stroke at presser up		1	8~50	10	Input
P5-7*	Pedal Stroke at Trimming Start 2	Pedal Stroke at Trimming Start 2		1	-60~10	-51	Input
P5-8*	Pedal Stroke at High-speed Running	Pedal stroke at high-speed running		1	10~150	150	Input
P5-9*	Correction of Pedal Middle Position	Correction of pedal's middle position		1	-15~15	0	Input
P5-10*	Presser Auto Up Holding Time	The holding time of presser auto-up	s	1	2~250	10	Input
P5-11*	Pedal Stroke at Trimming Start 1	Pedal Stroke at Trimming Start 1		1	-60~10	-51	Input
P5-12*	Presser Action Time	Time for lowering the presser after up		10	0~250	140	Input
P5-13	Presser up after	Presser up after trimming			0:OFF:No	1	Selection



	Trim				1:ON:Yes		
P5-14*	Presser up Full Output Time	The time for full pressure output at presser up	ms	5	50~250	150	Input
P5-15*	Presser up Output Duty Cycle	Output duty cycle at presser up		1	0~100	30	Input
P5-16	Soft Down at Presser up	Soft down after presser is up			0:FAS:Fast 1:SLW:Slow	0	Select
P5-17*	Select Pedal Curve	Select pedal curve		1	0~2	0	Input

\*The parameters with mark “\*” should be changed under the guide of the professional technicians.

## 6、Optional Device:

Code	Brief	Description	Unit	Step Length	Range	Default Value	Type
P6-0	Anti-coiling	Effective when the head with anti-coiling function is installed			0:OFF: No Anti-coiling 1:ON:Have Anti-coiling 2:SLM:Thread-loosing after Catching Thread	0	Select
P6-1	Release Upper Thread at Coiling	Effective when the head with anti-coiling function is installed			0:OFF:No 1:ON:Yes	0	Select
P6-2	Stitch Number for Releasing Upper Thread	Set stitch number from sewing start to releasing thread	Stitch	1	0~30	1	Input

## 7、Operation Head:

Code	Brief	Description	Unit	Step Length	Range	Default Value	Type
P7-0	Buzzer Voice	Set the voice of buzzer			0:OFF:No Voice 1:PAR:Panel Voice 2:ALL:Panel + Alarm Voice	2	Select
P7-1	Backlight Auto Off	Backlight auto off switch			0:OF:No Auto Off 1:ON: Auto Off	0	Select
P7-2	Backlight Auto Off Time	Backlight auto off waiting time	min	1	1~9	3	Input
P7-3	Language	Select language			0:CH:中文 1:EN:English	0	Select
P7-4	Customized Pattern Display Setting	Set display of customized pattern			0:STH:Stitch 1:SHP:Shape Outline	0	Select

## 8、Counter:

Code	Brief	Description	Unit	Step Length	Range	Default Value	Type
P8-0	Trim Counter Mode	Trim counter mode			0:OFF:Forbidden 1:ON:Permitted	1	Select
P8-1	Bottom Thread Counter Mode	Bottom thread counter mode			0:OFF:Forbidden 1:ON:Permitted	1	Select
P8-2	Clear Counter at Repower	Clear counter value at repowering machine			0:CLR:Clear 1:RSV:Reserve	1	Select
P8-3	Cannot Change Trim Counter	Cannot change trim counter			0:OFF:Permit Changing 1:ON:Forbid Changing	0	Select
P8-4	Cannot Change Bottom Thread Counter	Cannot change bottom thread counter			0:OFF:Permit Changing 1:ON:Forbid Changing	0	Select
P8-5	Machine Action at Trim Counter set Value	Action of sewing machine when the set value of trim counter is reached			0:OFF:Stop Sewing 1:ON:Keep Sewing	0	Select
P8-6	Machine Action at Bottom Thread Counter Set Value	Action of sewing machine when the set value of bottom thread counter is reached			0:OFF:Stop Sewing 1:ON:Keep Sewing	0	Select
P8-7	Counter Display	Counter Display Setting			0:OFF: Not Display 1:UP:Trim Counter Display 2:DN:Bottom Thread Counter Display	1	Select
P8-8	Bottom Thread Counter Unit	Unit for Bottom Thread Counter			0:10:10 Stitch 1:15:15 Stitch 2:20:20 Stitch	1	Select

## 9、Others:

Code	Brief	Description	Unit	Step Length	Range	Default Value	Type
P9-0	Stop Position	The pointed needle rod position for stopping the sewing machine			0:DN:Down Position 1:UP:Up Position	0	Select
P9-1	Panel Compensation Key Setting	Set compensation key of panel			0:HAF:Half Stitch 1:ONE:1 Stitch	0	Select
P9-2	Forbid	Forbid the			0:OFF:	1	Select

	Compensation after Turn Wheel	compensation action after turning the wheel			Compensation Effective 1:ON: Compensation Ineffective		
P9-3	Half Compensation Additional Function	Additional function of Half Stitch Compensation			0:GEN:General Action (Half Stitch Compensation) 1:ONE: One Stitch Compensation (Up Stop→Up Stop)	0	Selectio
P9-4	Thread Loose Number at Start	Thread-loosing stitch number at sewing start		1	0~9	0	Input
P9-5*	Pick Thread	Activate function for picking thread			0:OFF:Ineffective 1:ON:Effective	1	Selectio
P9-6*	Thread-picking Delay	Delay time of thread-picking	ms	1	0~250	170	Input
P9-7*	Swing Action Angle Adj.	Adjust the swing action angle		1	-50~50	0	Input
P9-8*	Feeding Action Angle Adj.	Adjust the frame-moving angle at feeding		1	-50~50	0	Input
P9-9	Lightness	Adjust lightness of lamp		5	0~100	50	Input
P9-10	Trim after frame-over alarm release	Trim thread after the frame-over alarm is released			0:OFF:Ineffective 1:ON:Effective	1	Selectio

\*The parameters with mark “\*” should be changed under the guide of the professional technicians. .

## 10、Repair & Maintenance:

Code	Brief	Description	Unit	Step Length	Range	Default Value	Type
P10-0	Needle Replacement Rest Value	Rest stitches for needle replacement	1000 Stitch	1	0~9999	0	Input
P10-1	Needle Replacement Set Value	Set stitches for needle replacement	1000 Stitch	1	0~9999	0	Input
P10-2	Clearing Time Rest Value	Rest hours for clearing	Hour	1	0~9999	0	Input
P10-3	Clearing Time Set Value	Set hours for clearing	Hour	1	0~9999	0	Input
P10-4	Oil Replacement Rest Value	Rest hours for oil replacement	Hour	1	0~9999	0	Input
P10-5	Oil Replacement Set Value	Set hours for oil replacement	Hour	1	0~9999	0	Input

[Note 1]: Parameters, like “P10-0”, “P10-2” and “P10-4” can not be set. User can only check them in the Internal Parameter Setting Interface

[Note 2]: After the modification of parameters for repair and maintenance, the corresponding parameters of “Rest Value” will be changed to the set value

[Note 3]: After the parameter value of repair and maintenance are set (value over 0), the corresponding counting function for repair and maintenance will be activated as well.

## 11、Special:



Code	Brief	Description	Unit	Step Length	Range	Default Value	Type
P11-0*	Max Speed	Max Speed of Head	rpm	50	50~5000	4000	Input
P11-1*	Frame-moving Method	Set frame-moving method		1	0~5	1	Input
P11-2*	Swing Motor Current	Set the current of swing motor		1	0~15	5	Input
P11-3*	Swing Motor Half Current Coefficient	Set the half current at swing motor		1	0~15	4	Input
P11-4*	Feeding Motor Current	Set the current of feeding motor		1	0~15	5	Input
P11-5*	Feeding Motor Half Current Coefficient	Set the half current at feeding motor		1	0~15	4	Input
P11-6	Strengthened	Use it when needle can not penetrate the cloth			0:GEN:General 1:TRY:Strengthened	0	Selectio
P11-7*	Model Selection	Select Model			0:SR 1:S 2:B	0	Selectio


\*The parameters with mark “\*” should be changed under the guide of the professional technicians. 。

### 3.13.3 Parameter Recovery and Back-up

User can save the changed parameter into U disk for the recovery operation in future


### 1、 Enter Parameter Transfer Interface:

Press  in Information Mode interface to enter the parameter management interface, where user needs press  .




### 2、 Back up Parameters

In the interface of parameter recovery and back-up, the default setting is to back-up the parameters.


After inserting the U disk, user needs press  . After the operation, the system will create catalogue called as “bakParam” in U disk automatically. The file “backup.param” within that catalogue is the parameter back-up file


**[Note]: the file with the same name will be replaced with new data. The original data will be lost.**

In parameter recovery operation, user can press  to shift to recovery mode.



### 3、Parameter Recovery


At recovery mode, press  to recover the parameters. After the operation, the system will return to the previous level.




### 3.13.4 Default Parameter Recovery


User can restore the parameters to their default values. Additionally, user can also save the set parameters for the usage in future.

#### 1、Enter Default Parameter Recover Interface:

Press  in Information Mode interface to enter the parameter management interface






In parameter management interface, press  and then input the password (the original password is the manufacturer ID). After user inputs the correct password, user can have access to Default Parameter Mode






Before entering the parameter encryption mode, user needs input passwords (The original password is manufacturer’s ID).

If the password is wrong, pressing  at each time will erase the first figure at left of icon. Pressing  will clear all the password inputted.

Input password and press .

## 2、Use the Default Parameter


Click the corresponding default parameter and then press  to reload that value




After the reloading, the system will return to the upper interface automatically

**[Note] Some important parameters, (like the “Special parameters”), can not be restored in this operation.**



### 3、 Save Customized Parameter

Press  to have access to the interface for saving parameters, where user can save the parameter value after the setting.


Click  or  to confirm the position for saving that parameter. Then click  to save it.



After the saving, the system will return to the upper interface automatically.

**[Note] The parameters for repair and maintenance can not be saved**

### 4、 Load Parameters Saved by User

Have access to that interface. Check the content on button “Customized Parameter (Y/N)”. If it is Y in the bracket, it means that position has customized parameter.

Click that key and press  to reload the corresponding parameter. After the operation, the system will return to the upper interface.



## 3.13.5 Parameter Encryption

User can set the password in each level under the parameter setting interface, so as to avoid the artificial mis-operation.




### 1. Enter Parameter Encryption Interface:


In information mode interface, press





to enter the parameter management in terface


In parameter management interface,


press , then system will ask for the password (default password is manufacturer ID).



### 2. Input Password:

If user inputs the wrong figure, pressing  will delete the first figure at left of the icon, while pressing  will delete the entire figures inputted.

Input the password and press .




## 2、 Select Parameter for Encryption:


As shown in picture, user can select one or many parameters for encryption. (Here, we select “Presser and Pedal”.)

压脚和踏板 : Selected

压脚和踏板 : Unselected


After selecting the parameter for encryption, user can press .

From then on, user has to input password when setting the parameter that was encrypted.



For changing password, please press .

**[Note] User has to input password at having access to the Special Parameter in each time.**

## 3、 Change Password

In the interface of setting new password, press  Cur-Password: ,  New-Password:  &  Confirm:  in order and input the current password, new password, confirmation respectively. At last press .

**[Note]: The original password is the manufacturer ID. After setting the password, the “Current Password” is the password set at last time**



### 3.13.6 Counter

- The counter contains the trimming counter and bottom thread counter. User can shift the type of counter via “Counter” → “Counter Display”.


- At trimming in each time, the value of trimming counter will increase. When it reaches the set value, the system will give warning.
- Bottom thread counter is to reduce the number set at “Counter” → “Bottom Thread Counter Unit” in each sewing. When the value reaches 0, the system will give warning

### 1、 Enter interface for setting counter

In information mode interface, press



to enter counter mode.




### 2、 Select the Counter for Setting


In counter mode interface, user can check the current value and set value of each counter.

If the counter is selected, the counter will be opened, which is determined by parameter “Counter” → “Trim Counter Mode” & “Bottom Thread Counter”.




### 3、 Set Counter

Example: How to set trim counter. The operation for setting the trim counter is similar to that of bottom thread counter. The only difference is at Bottom Thread Counter Activate()



**Functions:**

No.	Content
A	Shift the input between the set value and the current value (The button in shadow is the selected one).
B	Up Counter Switch (This button will be effective when it is in blue background).
C	Quit counter setting mode and return to previous interface.
D	Clear current value.
E	Display the set value and current value (User can input the value in the spot line frame)
F	Number keyboard, used to input set value and current value  Clear the value inputted currently
G	Confirm setting

[Note] if

the

parameter “Counter” → “Cannot Change Trim Counter” and “Cannot Change Bottom Thread Counter” is set at Forbid Changing, user will not enable to set the current value of counter

### 3.13.7 Display Settings

In information mode interface, press





to enter the display setting

mode, where user can set Backlight Auto Turn-off, Keyboard Lock and so on.



The setting content of display is shown as below:



#### 1、Backlight Auto Turn-off

By the set time, the backlight of screen will be turned off automatically.


Range: 1~9 min

Default Value: Invalid

Releasing Method: If the backlight is off, user can touch any position on the panel to turn it on.


#### 2、Keyboard Lock

When it is set as “Valid”, all the buttons will turn to grey in display and become useless.

Pressing  will directly return to main interface

Default Value: Invalid

Releasing Method: Hold the title bar at main interface for over 5 seconds, until user hear “Bee--m”. After that the lock is released. (After the releasing, this function will be set as Invalid)



### 3、Turn off Buzzer

When it is set as “Valid”, system will keep silence when user presses button.

Default Value: “Invalid”

### 4、Lightness Control

Adjust the lightness of the LCD screen. The larger value is, the lighter will be

Range: 1~100

Default Value: 50

### 5、Panel Display Style


Adjust the panel display style

Range: 0~1 (0: plastique, 1: windows)

Default Value: 0



Plastique Style




Windows Style


### 6、 Main Interface Background Color


Set the background color of the main interface


Press “Set” to open the color board



Select the color and press “OK”.



At this moment, the color display area will display the selected color. Press  to save and quit.




### 7、 Customized Pattern Display Setting


Set the display of customized pattern

Range: 0~1 (0: Stitch Form; 1: Shape Outline)

Default Value: 0



Stitch Form



Shape Outline

## 3.13.8 Software Version


1、 Enter the interface for checking software version:


Press **Ver.** in information mode interface to enter the software version mode.





## 2、Version Inquiry and Output


Check the software version in current interface. Press  to output the software version to the base catalogue of the U disk with name “version.png”.



## 3.13.9 Pattern Transfer


- Two ways are provided: “Memory to U Disk” and “U Disk to Memory”.
- Enable import/export customized pattern, customized front reverse sewing pattern and customized back reverse sewing pattern
- The supported versions are VDT, DST, DSB, SBK and JZQ
- U Disk Copy Path:
  - Customized Pattern: rand\_pat
  - Customized Front Reverse Sewing: h\_pat
  - Customized Back Reverse Sewing: t\_pat

### 1、Enter Pattern Transfer Mode:

In Information Mode interface, press  to enter pattern transfer mode.



## 2、Transfer Type


 : Customized Pattern


 : Customized Front


Reverse Sewing

 : Customized Back



Reverse Sewing








Here, we use the “Customized Pattern Transfer” as the example. Press  to enter the interface for pattern transfer.




### Functions:

A	Pattern List	Display the pattern list of panel or U disk
B	Page	The current page/total pages are displayed
C	Copy Mode Display	 : Memory Pattern List  : U Disk Pattern List
D	Select All	Select all the patterns.
E	Delete	Delete the selected pattern
F	Quit	Quit and Return to Upper Interface

G	Page Key	Turn the page.
H	Copy Mode Selection	<p>Load pattern from memory or U disk</p> <p> : Activate the Memory Load Mode: At this moment, user cannot load pattern from U disk.</p> <p> : Deactivate the Memory Load Mode: At this moment, user can load pattern from U disk.</p> <p> : Activate the U Disk Load Mode: At this moment, user can not load pattern from memory.</p> <p> : Deactivate the U Disk Load Mode: At this moment, user can load pattern from memory.</p> <p> : Shift between U Disk and Memory</p>
I	Enter	Confirm the operation.



**Operation:**


**1、 Copy Mode Selection**

The default setting is to copy pattern from memory to U disk, user can press  to change the copy mode.

**2、 File Selection**



Select the pattern for copy in the pattern list (here, we select No.001, 002, 003, 004 and 005).

If the patterns are so many, please use   to turn the page.



For copying all the patterns, please press . For deletion, please press .


**3、 Confirm the Copy**

After selection, please press . Then the system will display “Copy the Selected Pattern”, user can press  to perform the operation. If the pattern is copied from memory to U disk, the system will automatically create a directory at the base catalogue of U disk and save the pattern at there.

**[Note]: At the process of copy, if the memory contains the pattern with the number same to that of the pattern in the U disk, the new pattern will replace the old one.**

### 3.13.10 Alarm Records

#### 1、 Enter Alarm Record Mode:


In the information mode interface, press  , then system will ask for the manufacturer ID. After user gives the right ID, the system will have access to the alarm record mode.




#### 2、 Inquire Alarm Record

In this mode, the recent alarms will be recorded. The smaller number means the later the alarm is.

Additionally, it also records the thread-trimming numbers at alarm.


Press  to clear all the alarm records.



### 3.13.11 Running Records

#### 1、 Enter Running Record Mode:

In the information mode interface,


press  then system will ask for the manufacturer ID. After user gives the right ID, the system will have access to the running record mode



#### 2、 Check Running Records

- ① Accumulated Running Time: Record total sewing time of machine.
- ② Accumulated trimming Pieces: Record the total number of the trimming.
- ③ Accumulated Power-on Time: Record the total time of power-on
- ④ Accumulated Stitch Number: Record the total stitch number of the machine.


Additionally, click “Clear” to cleat the counting value



### 3.13.12 Formatting

#### 1、 Enter Formatting Mode:

In the information mode interface,

press  to enter formatting mode.



## 2、Formatting Operation

### 1) USB Formatting:


Press “USB” to delete all the patterns within the U disk. So user needs back up the data if necessary.

### 2) Customized Pattern Formatting

Press “Customized” to delete all the customized patterns within the USB.

### 3) Memory Formatting



Press “Memory” to delete all the patterns (Customized pattern, cyclic sewing patterns and continuous sewing patterns) within the memory.



## 3.13.13 Date and Time Setting

### 1、Enter Date and Time Setting Mode:

In the information mode interface,

press   to have access to the date and time setting mode.





### 2、Method for Setting Date:

Click “Year” (At here, it is 2012.)to display two arrows to adjust it


Click “Month” (At here, it is June) to display the list of months. User can select the proper month.

After the setting, the display of year and month will be refreshed to the right ones.

User can also use  &  to check the content in calendar.

Click the day to complete the setting.

**[Note]: User has to set year, month and date to finish the setting. Only setting the year and month will not complete this**



operation.


### 3、 Method for Setting Time:

In default, user has to set hour firstly. Press “hour” to shift the setting to minute (Pressing “hour” is to change it to “minute”) and then press the arrows to change the time

User can also click the display area to shift between hour and minute.


After the setting of date and time,

please press  to save it.



### 4、 Forbid to Change System Time

Once the machine is attached with the periodical passwords, the system will deny the change on the system time. After all the passwords are cleared, the system will unlock the setting of the system time.



## 3.13.14 Password Mode

- The password mode is used for setting the periodical password and payment date, which the system will ask the user to input for unlocking the machine.
- User needs set the board number carefully at setting the password. The board number is used to manage the password.
- At most 10 periodical passwords can be set.◦

In the information mode interface, press




to activate the interface for

inputting the user ID. Input the correct manufacturer ID to have access to the password management mode, where is used to set and manage the periodical password.


① At most 10 different password action times can be set.


② System can display the password information of the manufacturer.



### 1、Input Board Number

Press “Board Number” to enter the interface for inputting the board number. The board is formed by four figures; the range is from 0000 to 9999. This can be used for the management of the password by the manufacturer. After inputting the board

number, user can press  to finish the operation and return to the previous interface. (At here, we input 0001 as the board number).





### 2、 Confirm the System Clock


Press “Clock” to have access to the interface for setting system time and date. For changing the system clock, user needs press



after the modification (Refer to [3.13.13 Date and Time Setting], or press





to quit.





### 3、 Input the Super Password

Press “Super Password” to have access to the interface for inputting the super password.



At most 9 figures can be inputted, which are displayed as “•”. After user presses , the system will ask user to input that password again for confirmation.


If the inputted passwords in these two times are different, the system will ask user to input the super password again. After these two inputted passwords are same, user can press  to save it and quit.





#### 4、Input Activation Time and Periodical Password


Input “PW-1” to input the first activation date.

The activation date is the first time that the password is activated. This date shall be later than the system date.

Select the proper date and press  to finish the operation. At this moment, the system will turn to password input interface




The input method of the periodical password is same as that of the super password. After the confirmation, user needs press  to quit.




### 5、Continue Inputting Periodical Password

If user needs input the next activation date and password, he should repeat the operation at above. At most, ten dates and passwords can be inputted.


**[Note]: The next date shall be later than the previous one.**




### 6、 Save Password

Input the needed password, and then press  to save the entire information. The system will display “Password Saved Successful”.

After confirmation, the system will return to the previous interface.

**[Note]: Only when user set one periodical password, can  be displayed.**





### 7、 Clear Password before Activation


Clearing password positively is to delete the password before it activates.


The method for entering the password display interface is same as that of entering the password setting interface

After user input the right manufacturer ID, the system will display the current time and activation dates of periodical passwords, as shown in right figure


Press  to input the current password. The password is cleared in order of from early to latter



At this moment, user can input two passwords. If the inputted password is the current password, the current password will be deleted. If the super password is inputted, the entire passwords will be deleted. If the current password is deleted and the current password is the last password, the system will have no password any more. Press  to finish the operation.



The deactivated password is displayed in red, as shown in right. If all the passwords are deactivated, the system will automatically return to the previous level.



## 8、 Clear Password at Activation


If the system has the password and that password is not canceled, the password will activate at the set date. At this moment, user has to input the effective password to have the machine to work normally.


The effective passwords include the current password and the super password. If the inputted password is the current password, the current password will be deleted. If the super password is inputted, the entire password will be deleted. If the password is current password and the current password is the last password, the system will have no password any more. If the machine still have other passwords other than the current password, the next password will activate according to the set date



### 3.13.15 Software Update


#### 1、Enter Software Update Mode:


In the information mode interface, press  to enter the software update mode.




#### 2、Instruction

The updating software shall be located in the catalogue “Update” in U disk.


Click the content for update (the content in shadow is the selected), then press .



### 3.14 Test Mode

In the information mode interface, press  to have access to the test mode.








### Functions:

No.	Functions	Content
A	LCD Test	Test LCD displayer
B	Touching Panel Correction	Correct the touching panel
C	Input Signal Test	Test the input signal of switches and sensors
D	Speed Test	Test the speed of main shaft motor
E	Output Signal Test	Test the output signal of pressers and thread-trimming devices
F	Continuous Running	Set continuous running parameter and enter aging status
G	Swing/ Cloth-feeding Motor Adjustment	Test the origins of swing and cloth-feeding motor
H	Swing/ Feeding Test	for testing the swing/ feeding function solely
I	Shuttle Adjustment	Adjust the shuttle
J	Quit	Quit test mode and return to main interface

### 3.14.1 LCD Test

**Function:**


In the test mode, press  to activate LCD test function. Click the area other than the  to have LCD screen display white, black, red green and blue so that user can judge whether the LCD screen has problem.


Press  to return to the upper level interface.



### 3.14.2 Touching Panel Correction

**Functions:**


In the test mode, press . At this moment, the system will display “Confirm to enter touching panel correction mode?”

Press  to have access to the touching panel correction function.




User has to correct 5 spots. The touching pen is recommended to be used at touching the cross icon on the interface. After the correction, the system will display the result of this operation

**[Note]: During the correction, please perform the operation strictly according to the position of the cross icon, or the touching panel may become abnormal after the correction.**



### 3.14.3 Input Signal Test

#### Function:


In the test mode, press  to enter the Input Signal Test Function.


ON: Activation

OFF: Deactivation

Types of Input Signal:


- ① Swing Motor (X)
- ② Feeding Motor (Y)
- ③ Reverse Sewing Switch
- ④ Mirror Switch
- ⑤ Upper Needle Position
- ⑥ Reverse Sewing Lever (Range:0~1023)
- ⑦ Pedal (Range: 0~1023)
- ⑧ Main Shaft Angle (Range: 0~359)




Press  to return to the Previous level interface






### 3.14.4 Main Shaft Speed Test

#### Functions:

In the test mode, press  to set the main shaft speed test function.

Use  and  to set the aim speed of main shaft motor. After user presses , the main shaft motor will rotate in the set speed. At this moment, the actually measured speed will be displayed in the input column of actual speed.


Press  to stop running Press  to return to the upper level interface.





### 3.14.5 Output Signal Test


**Functions:**

In the test mode, press  to activate the output signal test function.



In this interface, user can press output signal button to test the status of output signals of solenoids

Output signals:

- ① Thread-stirring
- ② Thread-wiping
- ③ Thread-trimming
- ④ Thread-loosing
- ⑤ Presser
- ⑥ Reverse Sewing
- ⑦ Mirror LED
- ⑧ Light


Press  to return to the upper level interface.

**[Note]: The sewing machine will have the actual movement.**



### 3.14.6 Continuous Running

In the test mode, press  to set the continuous running function




## Functions:

No.	Function	Content
A	Pattern Display	Display the aging pattern
B	Pattern Selection Key	Select the aging pattern from the 20 basic patterns
C	Display and Setting of Swing Width	Display the swing value. Press it to enter the interface for setting the swing width.
D	Aging Time Setting	Please press SET to input the total time for aging
E	Aging Stage	Press it to set the ratio among stage 1, stage 2 and stage 3 and aging speed.
F	Time Interval	Set the time interval at aging
G	Running Time	Set the running time at aging.
H	Aging Process	Display the aging percentage and time used
I	Running	Press it to start aging. During the aging process, this button is displayed as "Pause".
J	Skip	Change the aging progress. <b>[Note] when the machine is running, you cannot change the aging progress.</b>
K	End	End the aging process manually
L	ESC	Quit the aging process and return to the previous level

### 3.14.7 Swing/ Cloth-feeding Motor Origin Detection

#### Function:

In the test mode, press  to activate the function for detecting the swing/ cloth-feeding motor origins.


In this interface, moving the XY motor with direction can have system display the real time status of sensors


ON: Sensor Detected

OFF: Sensor Undetected




is used to auto-return of motor.

Press  to back to the previous level




(双步进)


**[Note]: The sewing machine will have the actual movement.**



(单步进)

### 3.14.8 Shuttle Adjustment

In the test mode, pressing  is to enter the shuttle adjustment mode. The tested pattern is the 2-points zigzag at here.




#### Functions:

No.	Function	Content
A	Swing Width Display	Display the swing width
B	Set base line	Change base line position
C	Cloth-feeding Display	Display the cloth-feeding value 【注】单步进没有这个设置。
D	ESC	Quit and return to the previous interface
E	Value Adjustment	Adjust the swing width or cloth feeding amount

		Clicking the value frame of swing width or cloth-feeding amount is to confirm the value to adjust. Press the arrow to input value.
--	--	--

### 3.15 Manual Switches



#### 1) Reverse Feeding Switch ①

After user presses and holds the reverse feeding switch ①, the machine will feed the cloth reversely. Release the hand to turn the feeding to normal feeding.


#### 2) Symmetric Sewing Switch ②

When user selects scallop, random pattern or continuous sewing, this switch will function as symmetric sewing switch

Symmetric Inversion: when machine stops at the middle of sewing, user can press the symmetric inversion switch to sew the mirror of the pattern.

#### Sewing Method:

- 1) During the sewing, stop the machine at the position for symmetric inversion sewing
- 2) Press the symmetric inversion switch ②. After the switch is pressed, the LED will be on. (The switch only functions when machine stops, and it will become useless at running.)
- 3) Use the machine to do the symmetric inversion sewing.
- 4) Cut the thread or press the symmetric inversion switch again to end the sewing.



# 4 Appendix 1

## 4.1 Warning Information List

Number	Name of Malfunction	Sub-information Content
E-003	Head Tilt	Please turn off power 。
E-004	Main voltage is too low(300V)	Please turn off power and check the system hardware.
E-005	Main voltage is too high(300V)	No
E-007	IPM is over-voltage or over- current	Please turn off power and check the system hardware.
E-008	Voltage of assistant device (24V) is too high	Please turn off power and check the system hardware.
E-009	Voltage of assistant device (24V) is too low	Please turn off power and check the system hardware.
E-013	Encoder is error or unconnected.	Please turn off power and check the system hardware.
E-014	Motor running abnormal	Please turn off power and check the system hardware.
E-015	Exceeds sewing area	Please press Enter to release problem
E-016	Needle rod upper position abnormal	Please turn the wheel to adjust the needle rod position
E-020	Stepping software version error	Please turn off power 。
E-025	X origin detection abnormal	Please turn off power 。
E-026	Y origin detection abnormal	Please turn off power 。
E-027	Presser origin detection abnormal	Please turn off power 。
E-030	Stepping driver communication abnormal	Please turn off power 。
E-031	Stepping motor over-current	Please turn off power 。
E-032	Stepping driver power abnormal	Please turn off power 。
E-034	Abnormal current	Please turn off power 。
E-035	IPM over current frequently 1	Please turn off power 。
E-036	IPM over current frequently 2	Please turn off power 。
E-037	Motor is blocked 1	Please turn off power 。
E-038	Motor is blocked 2	Please turn off power 。
E-039	Motor over speed	Please turn off power 。
E-040	Over current in stop status	Please turn off power 。
E-041	Motor overload	Please turn off power 。
E-042	Bus voltage abnormal	Please turn off power 。
E-044	Head board EEPROM I/O Error	Please turn off power 。
E-045	Component abnormal	Please turn off power 。
E-046	CRC check error	Please turn off power 。
E-047	Data check error	Please turn off power 。
E-048	X check error	Please turn off power 。
E-049	Y check error	Please turn off power 。

Number	Name of Malfunction	Sub-information Content
E-050	MD1 stepping over-current	Please turn off power 。
E-051	MD1 X direction not finish	Please turn off power 。
E-052	MD1 Y direction not finish	Please turn off power 。

## 4.2 Hint Information List

Number	Name of Malfunction	Sub-information Content
M-001	Trim counter reaches set value	Press Enter
M-002	Bottom thread counter reaches MAX value	Press Enter
M-003	Set value is too large	Please input value within valid range
M-004	Set value is too small	Please input value within valid range
M-005	Save parameter abnormal	Press Enter to restore the default values
M-006	Memory full	Please delete the idle sewing data
M-007	Delete pattern data from memory?	Press ENTER to perform the deletion; Press ESC to quit the operation
M-008	Replace pattern data in memory?	Press ENTER to perform the replacement; Press ESC to quit the operation
M-009	Can not delete pattern data.	The selected sewing data is being used!
M-010	Format memory?	Press ENTER to perform the operation; Press ESC to quit the operation All the patterns within the memory will be deleted
M-011	Operation head not match to machine type	Please check the model and the software version
M-012	Wrong password	Please input again.
M-013	Hardware clock error	The hardware clock has problem, please contact manufacturer for repair.
M-014	Stitch number beyond range	Please reduce stitch number
M-015	Communication error	Abnormal event occurs in the communication between the operation head and the control box!
M-016	Copy the pointed pattern?	Replace the original pattern? Yes: Enter No: X
M-017	Copy all pattern data?	Press ENTER to perform the operation; Press ESC to quit the operation
M-018	Restore to default setting?	Press ENTER to perform the operation; Press ESC to quit the operation
M-019	USB is pulled out	U disk is pulled out!
M-020	Cannot find pattern data in U disk	–
M-021	No alarm record	–
M-022	Replace needle	Reach set value for needle replacement, please replace needle!
M-023	Replace oil	Reach set value for oil replacement, please replace oil!

Number	Name of Malfunction	Sub-information Content
M-024	Clean machine	Reach set value for cleaning machine, please clean machine!
M-025	Wrong User ID	Please input again.
M-026	Fail to confirm password	Please input password again
M-027	Cannot change system time	The periodical password is set. Can not change system time.
M-028	Fail to save password file	-
M-029	Fail to load password file	-
M-030	Password saved successfully	-
M-031	Fail to clear all passwords	Cannot delete password file
M-032	Fail to clear password	After the password is cleared, the file input becomes abnormal
M-033	Password file is deleted without authorization	Periodical password is deleted without authorization, please turn off machine
M-034	User ID file damage	-
M-035	Empty input invalid	Please input passwords
M-036	Password not match	Current password is wrong
M-037	New password is different.	Please input new passwords again and confirm it
M-038	Touching panel correction successful	Correction is successful. Please turn off power to restart.
M-039	Clear alarm records?	Are You Sure? Yes: Enter No: X
M-040	Delete the selected file?	Are You Sure? Yes: Enter No: X
M-041	Copy all patterns	Cover the original patterns? Yes: Enter No: X
M-042	Fail to copy file	Please check the space in memory
M-043	Fail to copy file	Please check if the USB disk is pulled!
M-044	Fail to open file	Fail to open file
M-045	Format not match	Formats don't match, current load denied
M-046	Parameter over range	Parameter is over range. After confirmation, the parameter over range will be restored according to the default parameters!
M-047	Please create catalogue and file	Please create catalogue bakParam in U disk. Name the back-up file as backup.param and copy it to bakParam catalogue!
M-048	File I/O error	File I/O error!
M-049	Please select file	Select the file for input/ output
M-050	File not exist	Cannot find the corresponding file
M-051	Enter touching panel correction mode?	Are You Sure? Yes: Enter No: X
M-052	Clear accumulated running time?	Are You Sure?

Number	Name of Malfunction	Sub-information Content
		Yes: Enter No: X
M-053	Clear accumulated trimming times?	Are You Sure? Yes: Enter No: X
M-054	Clear accumulated power-on time?	Are You Sure? Yes: Enter No: X
M-055	Clear accumulated stitch numbers?	Are You Sure? Yes: Enter No: X
M-056	Periodical passwords can't be same to super password	Please input password again
M-057	Cannot change trim counter	At change, please turn off setting
M-058	Cannot change bottom thread counter	At change, please turn off setting
M-059	Not select update item	Please select item for updating. At least select one item
M-060	Some selected update items don't exist.	The item not existing will be cancelled after return.
M-061	Update successful	Update is successful, please restart machine.
M-062	Format U Disk?	Press Enter to perform formatting operation. Press Esc to quit current operation. After formatting, all pattern files will be deleted.
M-063	Can not find U disk	Please insert the U disk for formatting!
M-064	Successful	Current operation is successful!
M-065	Failed	Current operation is failed!
M-066	Cover the pattern with same name in U disk?	Press ENTER to perform the replacement; Press ESC to quit the operation
M-067	Fail to correct touching panel	Please correct it again.
M-068	Restore all the settings?	Are You Sure? Yes: Enter No: X
M-069	Restore the selected item?	Are You Sure? Yes: Enter No: X
M-70	Not select item	Please select one or more parameters
M-71	SRAM initialization	Clear all data in SRAM. Please turn off power and restore the setting of DIP switch.
M-72	Turn off machine, Bye	-
M-73	Parameter recovery successful	Parameter recovery is successful, please restart machine
M-74	Software version saving successful	Software version is saved to the base catalogue of U disk successfully
M-75	Can not find pattern number	Please select pattern again
M-77	Can not register the sewing method of the pattern as pattern number	Please change sewing method.
M-78	Cannot find corresponding pattern file or fail to load pattern	Please select pattern file again.
M-79	Fail to create pattern file	Please select pattern file again



Number	Name of Malfunction	Sub-information Content
M-80	Parameter value over limits	Please check parameter setting
M-81	Index number over limits	Please select index number again
M-82	Not find registered pattern in memory	Please save a pattern into memory
M-83	Fail to replace the pattern	-
M-84	Cannot delete reverse sewing data	The selected reverse sewing data is being used!
M-85	Format customized pattern?	Press Enter to perform formatting operation. Press Esc to quit current operation. After formatting, all customized pattern files will be deleted!
M-89	Fail to replace current pattern	The copy group contains the current pattern number. Cannot replace current pattern.
M-90	Cannot find pattern file	Fail to perform operation to pattern file. Please select file again
M-91	Pattern data error	The generated pattern data is wrong, not supported by machine. Please check or select file again
M-92	Cannot delete pattern file	This pattern is forbidden to get deleting
M-93	Step error	The selected step cannot find in current operation. Please select again.
M-94	Load VDT file error	System doesn't support this VDT file or the VDT file is damaged
M-95	Write VDT file error	Fail at writing the VDT file. The number of file is over the max amount supported by system or the file is wrong
M-96	VDT data error	Cannot recognize the VDT data or the VDT file is damaged.
M-97	Can not transfer this pattern	Please confirm pattern
M-98	Format of transferred pattern error	Please confirm pattern
M-99	Data of transferred pattern is too long	Please confirm pattern
M-100	Cannot open the transferred pattern	Please confirm pattern
M-101	Cannot delete front reverse sewing file	File is being used
M-102	Cannot delete back reverse sewing file	File is being used
M-103	Sewing range over left limits	Please check parameter setting
M-104	Sewing range over right limits	Please check parameter setting
M-105	Swing over limits	Please check parameter setting
M-106	Feeding amount over limit	Please check parameter setting
M-107	Scale over limits	Please check parameter setting
M-108	Speed over limits	Please check parameter setting
M-109	Pattern number is full	Please delete the idle sewing data
M-110	Single stitch over length limits	The step length is over 12.7 or below 0.1. Please check pattern data.
M-111	Pattern number exited	Select an empty number
M-112	No pattern quoted in continuous sewing	At least add one pattern.
M-113	Stitch number of quoted patterns in	Please change the pattern stitch number

<b>Number</b>	<b>Name of Malfunction</b>	<b>Sub-information Content</b>
	continuous sewing is 0	
M-114	Front reverse sewing data invalid	-
M-115	Back reverse sewing data invalid	-
M-116	Front reverse sewing stitch number over limits	-
M-117	Back reverse sewing stitch number over limits	-

## 5 Appendix 2

### 5.1 Installation Size of Control Box




Figure 1 Installation Size (4 Holes)






Figure 2 Installation Size (3 Holes)

## 5.2 Installation Size of Touching Panel



### 5.3 SC300 Diagram



【注 1】双步进款没有倒缝电磁铁。

【注 2】单步进带剪线款没有 Y 步进电机、Y 原点传感器和倒缝扳手。

【注 3】单步进不带剪线款没有所有电磁铁、Y 步进电机、Y 原点传感器、油盘风扇、倒缝开关和倒缝扳手。