


PARTS BOOOK

CATENACCIO 43F
CATENACCIO 65HF

Electronic bartacking sewing machine




1.機殻部件 / FRAME&MISCELLANEOUS COVER COMPONENTS




PART NO. 图号	名 称	DESCRIPTION	Q' TY
1	后罩	MOTOR COVER	1
2	螺钉 M4 L=10	SCREW M4 L=10	4
3	上盖	UPSIDE COVER	1
4	螺钉 M6 L=12	SCREW M6 L=12	6
7	左盖板	BED COVER LEFT	1
8	右盖板	BED COVER RIGHT	1
9	螺钉M4 L=6	SCREW M4 L=6	5
10	面板盖	FACE COVER	1
11	面板	FACE PLATE	1
12	螺钉M4 L=10	SCREW M4 L=10	2
15	梭床罩	CYLINDER ARM CAP	1
16	圆柱销	HOOK COVER PRESSER SPRING PIN	1
17	梭床罩弹簧板A	HOOK COVER PRESSER SPRING A	1
18	梭床罩弹簧板B	HOOK COVER PRESSER SPRING B	1
19	螺钉M4 L=10	SCREW M4 L=10	1
20	螺钉M4 L=11	SCREW M4 L=11	3
21	销 8X30	PIN 8X30	2
22	螺钉 M6 L=6	SCREW M6 L=6	4
23	小夹线器组件	BOBBIN THREAD TENSION ASM.	1
24	小夹线器螺钉	BOBBIN THREAD TENSION ROD ASM.	(1)
25	小夹线板	THREAD TENSION DISK	(2)
26	小夹线簧	CONNECTING ROD SPRING	(1)
27	小夹线螺母	THREAD TENSION NUT	(1)
28	小夹线器紧固螺母	NUT 11/64-40	(1)
29	挑线杆护罩	BALANCE COVER	1
30	螺钉M3 L=8	SCREW M3 L=8	2
31	后过线器	THREAD GUIDE NO.1	1
32	螺钉 M6 L=12	SCREW M6 L=12	1
33	中部双眼过线	THREAD GUIDE PLATE	1
34	螺钉M6 L=12	SCREW M6 L=12	1
35	拦线杆	L SHAPED THREAD GUIDE A	1
36	螺母M4	NUT M4	1
37	上过线钩	ARM THREAD GUIDE A	1
38	螺钉M4 L=6	SCREW M4 L=6	1
39	下过线钩	TAKE-UP THREAD GUIDE B	1
40	螺钉M4 L=8	SCREW M4 L=8	1
41	过线器	FRAME THREAD GUIDE	1
42	螺钉M4 L=8	SCREW M4 L=8	1
43	警告牌	CAUTION LABEL(25)	1
44	螺钉M3 X 6	SCREW M3 X 6	1
45	割线刀	THREAD CUTTER	1
46	安全牌	SAFETY LABEL 12	1

1.機殻部件 / FRAME&MISCELLANEOUS COVER COMPONENTS




PART NO. 图号	名 称	DESCRIPTION	Q' TY
47	接地牌	GROUND MARK	1
48	橡膠塞	RUBBER PLUG	2
49	橡膠塞	RUBBER PLUG	2
50	橡膠塞	RUBBER PLUG	6
51	橡膠塞	RUBBER PLUG	1
52	橡膠塞	RUBBER PLUG	1
53	橡膠塞	RUBBER PLUG	1
54	橡膠塞	RUBBER PLUG	2
55	橡膠塞	RUBBER PLUG	3
56	梭子繞綫器	BOBBIN WINDER UNIT	1
57	環扣	RETAINING RING	(1)
58	開口擋圈4	E-RING 4	(1)
59	軸承墊圈	BTW BEARING SPACER	(1)
60	梭簧	BOBBIN SPRING	(1)
61	繞綫器拉簧	BTW SPRING	(1)
62	繞綫器底座	BTW BASE	(1)
63	繞綫器凸墊板	BTW CAM PLATE	(1)
64	繞綫器主柱	BTW SHAFT	(1)
65	繞綫器杠杆軸	BTW LEVER SHAFT	(1)
66	繞綫器杠杆	BTW LEVER	(1)
67	螺釘	SCREW	(1)
68	墊圈4.5X10X0.8	WASHER 4.5X10X0.8	(1)
69	繞綫器底座傳動軸	BTW BASE SHAFT	(1)
70	軸承	BTW BEARING	(2)
71	輪	BTW SHAFT BASE	(1)
72	繞綫器軸座	BTW SPACER	(1)
73	凸輪杆	BTW CAM LEVER	(1)
74	螺釘M5 L=5	SCREW M5 L=5	(1)
75	輪	BTW WHEEL	(1)
76	螺釘M4X8	SCREW M4X8	(2)
77	扭力彈簧	BTW TORSION SPRING	(1)
78	橡膠輪	BTW WHEEL RUBBER	(1)
81	針杆上帽套	NEEDLE BAR UPPER BUSH CAP	1

2.主軸與針杆部件 / MAIN SHAFT&NEEDLE BAR COMPONENTS



PART NO. 图号	名 称	DESCRIPTION	Q' TY
1	主軸電機	MAIN MOTOR	1
2	電機安裝螺釘	SCREW 11/64-40 L=14	4
3	聯軸器橡膠圈	RUBBER RING	1
4	聯軸器A	COUPLING A	1
5	聯軸器B	COUPLING B	1
6	螺釘M6 L=8	SCREW M6 L=8	10
7	軸承D=35X62	BEARING D=35X62	1
8	墊圈	WASHER	1
9	擋圈	RING	1
10	螺釘1/4-40 L=6	SCREW 1/4-40 L=6	2
11	蝸杆	WORM ASM	1
12	蝸杆螺釘11/64 L=12	SCREW 11/64 L=12	4
13	軸承6004	BEARING 6004	2
14	軸套B	BEARING BUSHU B	1
15	上軸傳動齒輪	HAND PULLEY GEAR A	1
16	螺釘11/64 L=4	SCREW 11/64 L=4	4
17	繞綫器輪	BOBBIN WINDER DRIVING WHEEL	1
18	繞綫器輪螺釘M5 L=6	SCREW M5 L=6	2
19	手輪軸齒輪	HAND PULLEY GEAR	1
20	上軸	MAIN SHAFT	1
21	彈簧	SPRING	1
22	手輪軸	HAND PULLEY SHAFT	1
23	銷子4X14	SPRING PIN 4X14	1
24	手輪	PULLEY	1
25	手輪緊固螺釘	HANDWHEEL SET SCREW	1
26	手輪方向指示標記	REVOLVING DIRECTION LABEL	1
27	軸套A	BEARING BUSHU A	1
28	螺釘M6 L=12	SCREW	1
29	針杆曲柄	COUNTER WEIGHT	1
30	針杆曲柄緊定螺釘	BOLT M8 L=12	1
31	針杆曲柄定位螺釘	COUNTER WEIGHT SCREW	1
32	墊圈11.6X8.2X0.6	WASHER 11.6X8.2X0.6	1
33	挑綫曲柄螺釘M6X0.75 L=6	SCREW M6X0.75 L=6	1
34	挑綫杆組件	LINK THREAD TAKE-UP	1
35	挑綫杆	THREAD TAKE-UP LEVER	1
36	軸承	BEARING	1
37	軸承	BEARING	1
38	軸承	BEARING	1
39	挑綫連杆	THREAD TAKE-UP CRANK	1
40	挑綫曲柄	NEEDLE ROD CRANK	1
41	滑塊	SLIDE BLOCK	1
42	針杆連杆	NEEDLE BAR CRANK ROD	1


2.主軸與針杆部件 / MAIN SHAFT&NEEDLE BAR COMPONENTS



PART NO. 图号	名 称	DESCRIPTION	Q' TY
43	襯套	NEEDLE BAR CRANK METAL	1
44	軸承	BEARING	1
45	挑綫曲柄左旋螺釘	LEFT SCREW	1
46	擋圈	THRUST COLLAR	1
47	螺釘	THRUST COLLAR SCREW	1
48	螺釘	THRUST COLLAR SCREW	1
49	橡膠圈	BEARING SUPPORT	2
50	滾針軸承	BEARING	2
51	螺釘M6 L=8	SCREW M6 L=8	1
52	挑綫連杆銷	THREAD TAKE UP CRANK SHAFT	1
53	針杆上套	NEEDLE ROD METAL	1
54	針杆下套	NEEDLE ROD LOWER METAL	1
55	針杆連接柱	NEEDLE BAR CLAMP	1
56	針杆連接柱螺釘9/64-40 L=6	SCREW 9/64-40 L=6	1
57	針杆	NEEDLE BAR	1
58	機針螺釘M3 L=5	SCREW M3 L=5	1
59	針杆導綫器	NEEDLE BAR THREAD GUIDE	1
60	下過綫器	THREAD GUIDE	1
61	機針DPX5 14# (DPX17 21#)	NEEDLE DPX5 14# (DPX17 21#)	1


3.PRESSER LIFTER & WIPER COMPONENTS

压脚提升部件




序号	图号	名称	DESCRIPTION	数量
1	400-29903	压脚提升电机	PRESSER LIFTING MOTOR	1
2	SM-4051655-SP	螺丝 M5 L=16	SCREW M5 L=16	4
3	SB-1100024-00	轴承	BEARING	0
4	SM-6040802-TP	螺丝 M5×0.7 L=8	SCREW M4×0.7 L=8	1
5	235-17501	滚子A	NEEDLE CAM ROLLER A	1
6	400-40256	铰链螺钉	CAM ROLLER SHAFT	1
7	NM-6040001-SP	螺母 M4×0.7	NUT M4×0.7	2
8	400-06661	提升连杆组件	LIFTEN LINK A ASM	1
9	400-06716	剪线轴	THREAD TRIMMER SHAFT	1
10	SM-8060812-TP	螺钉 M6 L=8	SCREW M6 L=8	1
11	400-23831	复位弹簧勾	SPRING RACK	1
12	SM-4040855-SP	螺钉	SCREW	1
13	135-15606	弹簧	SPRING	1
14	400-06666	传感器板	SENSOR SLIT ASM	1
15	SM-8050402-TP	传感器板安装螺钉	SCREW	2
16	400-10443	传感器安装座	SENSOR INSTALLING BASE	1
17	SM-6040802-TP	传感器板安装螺钉 M4×0.7 L=8	SCREW M4×0.7 L=8	1
18	HD-0005700-0A	传感器	PHOTO SENSOR	1
19	SL-4031291-SC	传感器安装螺钉 M3×12	SCREW M3×12	1
20	400-06665	提升连杆B	LIFTER LINK B	1
21	SD-0800327-TP	铰链螺钉 D=8 H=3.2	HINGE SCREW D=8 H=3.2	1
22	NM-6050001-SP	螺母 M5	NUT M5	1
23	SD-0700406-TP	铰链螺钉 D=7 H=4	HINGE SCREW D=7 H=4	1
24	400-06671	连接臂	CONNECTING ARM	1
25	SM-6061802-TP	螺钉 M6 L=8	SCREW M6 L=8	1
26	265-00405	连接轴	CONNECTING SHAFT	1
27	400-08693	压脚启动板曲柄	LOWERING ARM	1
28	SM-6061802-TP	螺钉 M6 L=18	SCREW M6 L=18	1
29	SD-07906006-TP	铰链螺钉 D=7.79 H=6	HINGE SCREW D=7.94 H=6	1
30	NM-6060001-CP	螺母 M6	NUT M6	1
31	400-06672	压脚启动板	LOWERING FOOL	1
32	141-04400	连杆	CONNECTING LINK	1
33	SD-1000406-TP	铰链螺钉 D=10 H=4	HING SCREW D=10 H=4	2
34	400-06674	拔线联接杆	WIPER CONNECTING LINK	1
35	SD-0600206-TP	铰链螺钉 M=6 H=2	HINGE SCREW D=6 H=2	1
36	135-09708	弹簧	SPRING	1
37	400-10451	拔线联接螺钉杆	WIPER CONNECTING ARM ASM	1
38	RC-0470611-KP	卡簧 4.7	RETAINING RING 4.7	2
39	400-10455	拔线联接板	WIPER CONNECTING LINK SHAFT	1
40	400-10457	挑线连杆挡块	WIPER STOPPER	1
41	400-10458	拔线联接杆	WIPER CONNECTING PLATE	1
42	400-17202	拔线器组件C	WIPER C ASM	1
43	NM-6060003-SC	螺母 M6	NUT M6	1
44	RC-0470611-KP	卡簧 4.7	RETAINING RING 4.7	1
45	SD-0640216-TP	铰链螺钉 D=6.35 H=2.1	HINGE SCREW D=6.35 H=2.1	1
46	400-06678	拔线器底板	WIPER BASE PLATE	1
47	SM-4040855-SP	螺钉	SCREW	1
48	WP-0450801-SP	垫片	WASHER	1
49	WP-0450801-SP	垫片	WASHER	1
50	WP-0480856-SP	垫片 4.8×8.4×0.8	WASHER 4.8×8.4×0.8	1

4. 擺梭、傳動部件 / SHUTTLE DRIVER SHAFT COMPONENTS



PART NO. 图号	名 称	DESCRIPTION	Q' TY
1	擺動齒	OSCILLATOR	1
2	梭床體組件	SHUTTLE ASM.	1
3	梭床體	SHUTTLE	(1)
4	下軸前套	SHUTTLE NEEDLE OUTER RING	(1)
5	梭床潤滑板	SHUTTLE LUBRICATING PLATE	(1)
6	梭床體油氈	SHUTTLE ONCE THROUGH OIL FELT	(1)
7	梭床體潤滑板螺釘9/64-40 L=4	SCREW 9/64-40 L=4	(2)
8	前套墊圈9.5X14.8X2.6	WASHER 9.5X14.8X2.6	(1)
9	梭床體油綫	OIL WICK	(1.06)
10	梭床體長油氈柱	SHUTTLE OIL FELT,A	(2)
11	油綫套管	VINYL PIPE	(0.66)
12	梭床體短油氈柱	SHUTTLE OOIL FELT,B	(1)
13	內鉤壓緊組件	INNER HOOK PRESSER ASM.	(2)
14	內鉤壓簧	INNER HOOK PRESSER SPRING	(2)
15	開口擋圈3	E-RING 3	(2)
16	油綫	OIL WICK	(0.43)
17	梭床體油氈壓板	ONCE THROUGH OIL FELT PRESSER	(1)
18	油氈壓板螺釘3/32-56 L=3.5	SCREW 3/32-56 L=3.5	(2)
19	油綫管	OIL TUBE	(0.19)
20	擺動齒墊圈	WASHER	1
21	停車檢測開關安裝板	SENSOR INSTALLING BASE	1
22	停車檢測開關	SENSOR INSTALLING	1
23	螺釘M3 L=12	SCREW M3 L=12	1
25	下軸后套	LOWER SHAFT REAR METAL	1
26	下軸	LOWER SHAFT GEAR ASM.	1
27	下軸滾針軸承	BEARING	3
31	后套墊圈	LOWER SHAFT THRUST WASHER	1
32	梭托組件	DRIVER ASM.	*
33	梭托	SHUTTLE DRIVER	1
34	梭托螺釘3/16-28 L=12.0	SCREW 3/16-28 L=12.0	1
35	梭床分綫簧	SHUTTLE UPPER SPRING	1
36	梭床分綫簧	SHUTTLE UPPER SPRING	1
37	梭床分綫簧	SHUTTLE UPPER SPRING	1
38	梭擺	INNER HOOK	1
39	梭擺(厚料)	SHUTTLE	1
40	梭床體調節軸	SHUTTLE RACE ADJUSTING SHAFT	1
41	梭芯	BOBBIN	1
42	梭芯套	BOBBIN CASE ASM.(RACING PREVE)	1
43	下軸擋圈組件D=8 W=8	THRUST COLLAR ASM.D=8 W=8	1
44	擺動齒擋圈D=7.94 W8	THRUST COLLAR D=7.94 W8	1
45	擺動齒軸擋圈組件D=12 W=10	THRUST COLLAR ASM.D=12 W=10	1
46	擺動齒擋圈螺釘11/64-40 L=4.5	SCREW 11/64-40 L=4.5	2


4. 擺梭、傳動部件 / SHUTTLE DRIVER SHAFT COMPONENTS



PART NO. 图号	名 称	DESCRIPTION	Q' TY
47	擺動連杆軸位螺釘螺母1/4-40	NUT 1/4-40	1
48	擺動齒軸開口擋圈8	E-RING 8	1
49	擺梭連杆軸位螺釘D=8 H=10.2	HINGE SCREW D=8 H=10.2	1
50	梭床分錢簧螺釘3/32-56 L=3.5	SCREW 3/32-56 L=3.5	2
51	梭床體固定螺釘M4 L=6	SCREW M4 L=6	1
53	梭床體緊定螺釘M6X8	SCREW M6X8	1
54	擺動齒軸緊定螺釘M6X6	SCREW M6X6	2
55	連杆上蓋螺釘11/64-40 L=10.5	SCREW 11/64-40 L=10.5	2
56	梭床	SHUTTLE RACE PING ASM.,C	1
57	梭床	INNER HOOK PRESSER ASM.,A	(1)
58	梭床	INNER HOOK PRESSER ASM.,B	(1)
59	擺動齒軸	OSCILLATING ECCENTRIC SHAFT	1
60	擺梭連杆	CRANK ROD	1
61	蝸輪組件	WORM WHEEL ASM.	1
62	螺釘1/4-40 L=11	SCREW 1/4-40 L=11	1
63	蝸輪座定位螺釘3/8-28 L=19.5	SCREW 3/8-28 L=19.5	1
64	內六角螺釘M6X8	SCREW M6X8	1
65	送布凸輪軸軸套	WORM WHEEL SHAFT BUSHING	1
66	螺釘1/4-40 L=10	SCREW 1/4-40 L=10	2
67	送布凸輪軸擋圈D=18 W=12	THRUSR COLLAR ASM.D=18 W=12	1
68	螺母1/4	NUT 1/4	1
69	送布凸輪軸組件	WORM WHEEL SHAFT ASM.	1
70	定位銷	CAM GUIDE PIN	1
71	螺母9/16-20	NUT 9/16-20	1
72	送布凸輪	FEED CAM	1
73	螺釘1/4-40 L=11	SCREW 1/4-40 L=11	1
74	檢測板組件	SENSING BOARD ASM.	1


5.THREAD TRIMMER MECHANISM COMPONENTS

自动剪线部件




序号	图号	名称	DESCRIPTION	数量
1	400-06711	剪线凸轮	THREAD TRIMMER CAM	1
2	SM-8050592-TP	螺钉	SCREW WASHER	2
3	WP-0450801-SP	垫片	WASHER	1
4	400-40256	凸轮滚子轴	CAM ROLLER SHAFT	1
5	NM-6040001-SP	螺母 M4×0.7	NUT M4×0.7	2
6	400-06712	剪线杠杆	THREAD TRIMMER LINK ASM	1
7	SD-0800327-TP	轴位螺钉 D=8 H=3.2	HINGE SCREW D=8 H=3.2	1
8	NM-6050001-SP	螺母 M5	NUT M5	1
9	400-06716	铰链轴	THREAD TRIMMER SHAFT	1
10	SM-8060812-TP	螺钉 M6 L=8	SCREW M6 L=8	1
11	400-06717	剪线连杆	CONNECTING BAR	1
12	400-10525	剪线感应板	THREAD TRIMMER SENSOR SLIT	1
13	SM-6040802-TP	螺钉 M4×0.7 L=8	SCREW M4×0.7 L=8	1
14	HD-0022300-00	剪线传感器	PHOTO SENSOR	1
15	SL-4041291-SC	螺钉 M4 L=12	SCREW M4 L=12	1
16	400-10526	传感器安装座	THREAD TRIMMER SENSOR BASE	1
17	SM-4040855-SP	螺钉	SCREW	2
18	400-06722	针板组件 A	NEEDLE PLATE ASM A	1
19	400-06723	针板组件 H	NEEDLE PLATE ASM H	1
20	400-06724	针板组件 E	NEEDLE PLATE ASM E	1
21	B2417-280-000	剪线杠杆轴	THREAD CUTTER LEVER SHAFT	(1
22	B2426-280-000	引针孔	NEEDLE HOLE GUIDE	(1
23	141-09607	引针孔	NEEDLE HOLE GUIDE	(1
24	D2426-282-C00	引针孔	NEEDLE HOLE GUIDE	(1
25	SS-1060210-TP	螺钉 3/32-56 L=2.2	SCREW 3/32-56 L=2.2	(2
26	400-06721	针板	NEEDLE PLATE	(1
27	B2424-280-000	固定刀	FIXING KNIFE	(1
28	SS-7090410-SP	轴位螺钉 9/64-40 L=3.5	SCREW 9/64-40 L=3.5	(2
29	B2418-280-000	动刀连杆	MOVING KNIFE LINK	(1
30	B2416-280-000	剪线杠杆套	THREAD CUTTING LEVER RING	(1
31	B2415-280-0A0	剪线杠杆组件(小)	THREAD CUTTER LEVER ASM SMALL	(1
32	B2414-280-0A0	剪线杠杆组件(大)	THREAD CUTTER LEVER ASM LARGE	(1
33	SS-6110430-TP	螺钉 11/64-40 L=4.0	SCREW 11/64-40 L=4.0	(1
34	WP-0450846-SP	垫片	WASHER	(1
35	SS-7110740-TP	螺钉 11/64-40 L=7	SCREW 11/64-40 L=7	(1
36	B2423-280-00C	动刀垫片C	MOVING KNIFE WASHER C	(1
37	B2423-280-00A	动刀垫片A	MOVING KNIFE WASHER A	(1
38	B2423-280-00B	动刀垫片B	MOVING KNIFE WASHER B	(1
39	B2423-280-00D	动刀垫片D	MOVING KNIFE WASHER D	(1
40	B2423-280-00E	动刀垫片E	MOVING KNIFE WASHER E	(1
41	B2421-280-0A0	动刀组件	MOVING KNIFE ASM	(1
42	SD-0500091-TP	铰链螺 D=5.0 H=0.9	HINGE SCREW D=5.0 H=0.9	(1
43	SM-1040650-TP	螺钉 M4 L=6	SCREW M4 L=6	4
44	263-15606	凸轮滚子 A	NEEDLE CAM ROLLER A	1
45	263-15705	凸轮滚子 B	NEEDLE CAM ROLLER B	1
46	263-15804	凸轮滚子 C	NEEDLE CAM ROLLER C	1
47	263-15903	凸轮滚子 D	NEEDLE CAM ROLLER D	1

6. 送料部件 / FEED MECHANISM COMPONENTS




PART NO. 图号	名 称	DESCRIPTION	Q' TY
1	螺釘11/64-40 L=7	SCREW 11/64-40 L=7	4
2	開口擋圈 6	E-SHAPED SNAP RING 6	2
3	墊圈8.5X14X1	WASHER 8.5X14X1	2
4	壓腳提升導板組件	LEVER DRIVING PLATE ASM.	2
5	拉簧	TENSION SPRING	2
6	左壓腳提升架	LIFTING LEVER,LEFT	1
7	提升架軸	LIFTING LEVER,SHAFT	1
8	送料架支撐板	SUPPORT PLATE	1
9	螺釘 M4 L=5	SCREW M4 L=5	2
10	鋼球 (1/8)	STEEL BALL (1/8)	7
11	鋼球座	BALL RETAINER	1
12	螺釘M=6 L=20	SCREW M=6 L=20	1
13	墊圈6.2X13X1	WASHER 6.2X13X1	1
14	拉簧掛銷	SPRING SUSPENSION	1
15	送料架	FEED BRACKET	1
16	螺釘15/64-28 L=4.7	SCREW 15/64-28 L=4.7	1
17	右壓腳提升架	LIFTING LEVER,RIGHT	1
18	螺釘1/8-44 L=2.8	SCREW 1/8-44 L=2.8	2
19	護手圈	FINGER GUARDE	1
20	螺釘11/64-40 L=8.7	SCREW 11/64-40 L=8.7	5
21	壓腳蓋板	WORK CLAMP FOOT FACEPLATE	1
22	右壓腳	WORK CLAMP FOOT,RIGHT	1
23	左壓腳	WORK CLAMP FOOT,LEFT	1
24	圓頭螺釘 M6 L=8	SCREW M6 L=8	1
25	墊圈6.2X13X1	WASHER 6.2X13X1	1
26	送料板	FEED PLATE	1
27	螺釘M4 L=5	SCREW M4 L=5	6
28	蓋板	FEED PLATE PRESSER PLATE	1
29	送料托架	FEED PLATE CARRIER BAR	1
30	針距調節器銷	FEED DRIVING ARM SHAFT	2
31	螺釘M6 L=8	SCREW M6 L=8	1
32	螺釘5/16-24 L=10	SCREW 5/16-24 L=10	1
33	螺母15/64-28	NUT 15/64-28	2
34	墊圈7X15X2	WASHER 7X15X2	1
35	橫向針距調節杆	FEED REGULATOR	1
36	橫向針距連動銷	HINGE STUD	1
37	螺母5/16-24	NUT 5/16-24	1
38	針距滑塊軸	FEED REGULATOR STUD	2
39	針距指示杆	INDICATOR LEVER	2
40	軸位螺釘D=5.3 H=2.2	HINGE SCREW D=5.3 H=2.2	2
41	針距滑塊	SLIDE BLOCK B	2
42	螺母1/4-40	NUT 1/4-40	2

6. 送料部件 / FEED MECHANISM COMPONENTS






PART NO. 图号	名 称	DESCRIPTION	Q' TY
43	墊圈6.5X13X0.8	WASHER 6.5X13X0.8	2
44	送料滾柱軸	FEED CAM ROLLER SHAFT	2
45	送料滾柱	FEED CAM ROLLER	2
46	橫向針距傳動杆	FEED DRIVING ARM	1
47	螺釘15/64-28 L=14	SCREW 15/64-28 L=14	1
48	針距座銷	FEED REGULATOR SHAFT	2
49	橡膠塞	RUBBER PLUG	2
50	托板	PLATE	1
51	螺釘11/64-40 L=8.5	SCREW 11/64-40 L=8.5	2
52	螺釘15/64-28 L=11.5	SCREW 15/64-28 L=11.5	1
53	墊圈7X15X2	WASHER 7X15X2	1
54	送料滑塊軸	SLIDE BLOCK STUD	1
55	送料滑塊	CRANK SLIDE BLOCK	1
56	螺釘15/64-28 L=10.5	SCREW 15/64-28 L=10.5	1
57	縱向針距調節杆	FEED ACROSS DRIVING ARM	1
58	縱向針距傳動杆	FEED ACROSS REGULATOR	1
59	螺釘M6 L=8	SCREW M6 L=8	1

7. 潤滑部件 / LUBRICATION COMPONENTS



PART NO. 图号	名 称	DESCRIPTION	Q' TY
1	油氈固定板	OIL SHIELD	2
2	油氈座	OIL SHIELD	1
3	螺釘M4 L=6	SCREW M4 L=6	2
4	螺釘M4 L=10	SCREW M4 L=10	1
5	長油氈	OIL FELT	1
6	油窗	OIL WINDOW	1
7	油窗	OIL GAUGE	1
8	橡皮塞	RUBBER PLUG	2
9	螺釘M4 L=6	SCREW M4 L=6	1
10	潤滑油氈	NEEDLE ROD CRANK LUBRICATING	1
11	油芯	OIL WICK	1.06
12	油盤組件	OIL PAN ASM	1
13	油盤	OIL PAN	(1)
14	油盤吸油綫	OIL WICK	(1)
15	機殼支撐橡膠墊	FRAME SUPPORT RUBBER	2
16	油盤固定螺釘D=3.8 L=20	SCREW D=3.8 L=20	4
17	油盤橡膠塞	RUBBER PLUG	2

8. 綫架及附屬部件 / LINE FRAME AND ANCILLARY COMPONENTS



PART NO. 图号	名 称	DESCRIPTION	Q' TY
1	綫架組件	THREAD STAND COMPONENTS	1
2	防護罩組件	SHIELD ASM.	1
3	油盤橡膠鉸鏈座	OIL PAN RUBBER HINGE SEAT	2
4	橡膠鉸鏈支架	RUBBER HINGE BRACKET	2
5	機頭支柱	HEAD PILLAR	1
6	加油器	OILER	1
7	廢油槽	WASTE SUMP	1
8	廢油瓶	WASTE OIL BOTTLE	1
9	木螺釘	WOOD SCREW D=3.1 L=16	
10	螺釘M6 L=75	SCREW M6 L=75	4
11	墊片6.1X12.2X1.5	WASHER 6.1X12.2X1.5	4
12	彈簧墊片	SPRING WASHER	4
13	螺帽M6	WASHER	8
14	螺絲刀(大)	SCREW DRIVER LARGE	1
15	螺絲刀(中)	SCREW DRIVER MIDDLE	1
16	螺絲刀(小)	SCREW DRIVER SMALL	1
17	內六角板手	HEXAGONAL SPANNER	1
18	扳手 (9X10)	WRENCH (9X10)	1
19	梭芯	BOBBIN	1
20	機針DPX5 14#	NEEDLE DPX5 14#	2

NOTES

This image shows a single page of white paper with horizontal blue or grey ruling lines. The lines are evenly spaced and run across the width of the page, leaving small margins at the top and bottom. There are no vertical margin lines, text, or other markings on the page.

Dealer:

The Texi logo, featuring a stylized purple flower icon followed by the word "texi" in a lowercase, italicized, purple serif font.