


Parts book
for blind stitch machine


Compacta




 *texi*




Ref.Nos.	Parts No.	Description
1	K-JJ500	Machine Frame
2	K1-02	Cylinder Bed
3	K1-03-A	Arm Side Cover
4	K1-04	Arm Side Cover Clamp Screw
5	K1-05-A	Pulley Cover
6	LD00005	Pulley Cover Set Screw
7	K1-07	Arm Rear Cover
8	LD00172	Arm Rear Cover Set Screw
9	K1-09	End Cover
10	LD00172	End Cover Set Screw
11	K1-11-D	Machine Base With Rubber Cushion
11	K1-11-D	Machine Base With Rubber Cushion
12	K1-12	Rubber Cushion(A)
13	K1-13	Rubber Cushion(B)
14	LD00535	Machine Base Clamp Screw
15	K1-15-D-HX	Motor
16	LD00006	Motor Bracket Set Screw
17	DQ00007	Motor Bracket Spring Washer
18	DQ00062	Motor Bracket Spring Washer
19	K5-55-1	Motor Belt
20	BZ1-13	Needle System Label(Lw x 6T)
21	K1-21	Thread Guide (Pig Tail)
22	LD00172	Thread Guide Set Screw
23		Thread Tension Assembly(Ref.Nos.24-29)
24	K1-24	Thread Tension Bracket
25	K1-25	Thread Tension Post
26	LM00011	Thread Tension Post Nut
27	K1-27-A	Thread Tension Disc
28	K1-28-B	Thread Tension Spring
29	K1-29	Thread Tension Nut
30	LM00172	Thread Tension Bracket Set Screw
31	LD00001	Thread Guide Stud Set Screw
32	K1-32	Thread Stand
33	K1-33	Thread Stand Base
34	K1-33	Plastic Cap
35	LM00027	Thread Stand Nut
36	DQ00008	Thread Stand Washer
37	K1-37	Disc Regulator (Moss-Green)
37	K1-37	Disc Regulator(Wine -Red)
38	LD00099	Disc Regulator Set Screw
39	K1-39	Disc Regulating Dial Screw
40	K1-40	Disc Regulating Dial Screw Prop
41	K1-41	Disc Regulating Plate Spring
42	LD00537	Disc Regulating Plate Spring Set Screw
43		Disc Regulating Indicating Label
44		Skip Stitch Label
45	K1-45	Cylinder Bed Connecting Hook
46	K1-46	Cylinder Bed Connecting Hook Screw
47	K1-47	Knee Lifter Crank
48	LD00535	Knee Lifter Crank Set Screw
49	K1-49	Knee Lifter Shaft
50	TXX00001	Knee Lifter Shaft Spring Pin
51	K1-51	Work Plate Bracket
52	LD00535	Work Plate Bracket Set Screw
53	K1-53	Work Plate
54	K1-54	Work Plate Wing Screw
55	K1-55	Work Plate Shaft
56	LD00535	Work Plate Shaft Set Screw
57	K2-20	Work Plate Shaft Collar
58	LD00003	Work Plate Shaft Collar Set Screw
59	K1-59	Work Plate Shaft Screwed Cap



Ref.Nos.	Parts No.	Description
1	K2-01	Main Shaft
2	K2-02	Main Shaft Bushing (Front)
3	LD00001	Main Shaft Bushing Set Screw
4	K2-04	Main Shaft Bushing (Rear)
5	LD00001	Main Shaft Bushing Set Screw
6		Main Shaft Thrust Washer
7	K2-07	Main Shaft Collar
8	LD00003	Main Shaft Collar Set Screw
9	K2-09-1-ZS	Pulley (Moss-Green)
9	K2-09-1-ZS	Pulley (Wine-Red)
10	LD00001	Pulley Set Screw
11		Eccentric Bushing
12	LD00003	Eccentric Bushing Set Screw
13	K2-13	Main Shaft Gear (Small)
14	LD00003	Main Shaft Gear Set Screw
15	K2-15	Main Shaft Gear (Large)
16	K2-16-1/K2-16-3	Skip Stitch Gear Eccentric Shaft
17	LD00063	Skip Stitch Gear Eccentric Shaft Set Screw
18	DQ00009	Skip Stitch Gear Eccentric Shaft Thrust Washer
19	K2-19/K2-19-3	Skip Stitch Gear Eccentric Shaft Fork
20	K2-20	Skip Stitch Gear Eccentric Shaft Collar
21	LD00003	Skip Stitch Gear Eccentric Shaft Collar Set Screw
22	K2-22	Connecting Link (Long)
23	K2-23	Connecting Link/Rod Holding Screw
24	TDQ00005	Connecting Link/Rod Holding Screw Snap Ring
25	DQ00010	Connecting Link/Rod Holding Screw Spring Washer
26	LM00011	Connecting Link/Rod Holding Screw Nut
27	K2-27	Connecting Rod
28	K2-28-1/K2-28-3	Skip Stitch Eccentric Shaft
29	K2-20	Skip Stitch Eccentric Shaft Collar
30	LD00003	Skip Stitch Eccentric Shaft Collar Set Screw
31	K2-31	Skip Stitch Lever Plate
32	LD00098	Skip Stitch Lever Plate Set Screw
33	GZ00001	Skip Stitch Lever Plate Ball
34	TH00019	Skip Stitch Lever Plate Spring
35	K2-35	Skip Stitch Lever
36	LD00001	Skip Stitch Set Screw
37	K2-37	Connecting Link (Short)
38	K2-38	Connecting Link Holding Pin
39	TDQ00005	Connecting Link Holding Pin Snap Ring
40	LD00004	Connecting Link Holding Pin Set Screw
41	K2-41	Connecting Block
42	LD00247	Connecting Block Set Screw
43	K2-43/K2-43-1	Ridge Forming Disc Shaft Assembly
44	K3-43	Ridge Forming Disc Shaft Collar
45	LD00004	Ridge Forming Disc Shaft Collar Set Screw
46	K2-46	Ridge Forming Disc Shaft Bushing
47	LD00004	Ridge Forming Disc Shaft Bushing Set Screw
48	K2-48	Cylinder Bed Shaft
49	LD00146	Cylinder Bed Shaft Set Screw
50	TDQ00001	Cylinder Bed Shaft Snap Ring
51	K2-51	Cylinder Bed Shaft Spring
52	K2-52	Cylinder Bed Shaft Spring Pin
53	K2-20	Cylinder Bed Shaft Collar
54	LD00003	Cylinder Bed Shaft Collar Set Screw




Ref.Nos.	Parts No.	Description
1	K3-01	Eccentric Bushing
2	LD00099	Eccentric Bushing Set Screw
3	LD00004	Screw
4	LD00008	Needle Yoke Center Screw
5	LM00012	Needle Yoke Center Screw Nut
6	K3-06	Needle Yoke & Ball Joint
7	K3-07	Needle Yoke Eccentric Pin
8	DQ00010	Needle Yoke Eccentric Pin Spring Washer
9	LM00017	Needle Yoke Eccentric Pin Nut
10	K3-10	Needle Carrier Shaft Crank
11	LD00247	Needle Carrier Shaft Crank Set Screw
12	K3-12	Needle Carrier Shaft Bushing
13	LD00004	Needle Carrier Shaft Bushing Set Screw
14	K3-14	Needle Carrier Shaft Collar
15	LD00003	Needle Carrier Shaft Collar Set Screw
16	K3-16	Needle Carrier Shaft "O" Ring
17	K3-17	Needle Carrier
18	LD00092	Needle Carrier Clamp Screw
19	K3-19	Needle Clamp
20	LD00508	Needle Clamp Set Screw
21	BZ1-13	Needle (LW x 6T)
22	K3-22*1*2	Looper Driver Crank
23	LD00001	Looper Driver Crank Set Screw
24	K3-24	Looper Yoke with Joint & Pin
25	LD00026	Looper Yoke Set Screw
26	K3-22	Looper Driver Crank Pin
27	K3-10-A	Needle Carrier Shaft
28	K3-28	Looper Carrier Assembly
29	LM00012	Looper Carrier Nut
30	LD00003	Looper Ball Joint Clamp Screw
31	LD00518	Looper Clamp Screw
32	K3-32	Looper
33	K3-33	Looper Ball Joint Pin
34	K3-34	Looper Ball Joint Eccentric Sleeve
35	LD00097	Looper Ball Joint Eccentric Sleeve Set Screw
36	K3-28*1*2	Looper Carrier Assembly
37	LD00004	Stitch Regulating Eccentric Set Screw
38	K3-38	Feed Lever
39	DQ00011	Feed Lever Thrust Washer
40	K3-40	Feed Lever Crank
41	K2-46	Feed Lever Crank Bushing
42	LD00084	Feed Lever Crank Bushing Set Screw
43	K3-43	Feed Lever Crank Collar
44	LD00004	Feed Lever Crank Collar Set Screw
45	A03-30	Feed Dog
46	DQ00012	Feed Dog Washer
47	LD00096	Feed Dog Set Screw
48	K3-48	Presser Foot Bracket
49	LD00520	Presser Foot Bracket Adjusting Screw
50	LD00172	Presser Foot Bracket Holding Screw
51	—————	Presser Foot Bracket Holding Screw Washer
52	LD00119	Presser Foot Holding Screw
53	LD00525	Presser Foot Clamp Screw
54	—————	Presser Foot Assembly(Ref.Nos.54-69)



Ref.Nos.	Parts N o.	Description
55	K3-55	Plain Presser Foot
56	K3-56	Chaining Finger
57	LD00522	Chaining Finger Set Screw
58	K3-58	Needle
58-1	LD00065	Screw(3/32-56×2)
59	LD00521	Needle Guide Set Screw
60	K3-60	Edge Guide
61	LD00522	Edge Guide Set Screw
62	K3-62	Cloth Retainer
63	LD00161	Cloth Retainer Screw
64	K3-64	Cloth Retainer Spring
65	K3-65	Cloth Retainer Eccentric Stud
66	LD00040	Cloth Retainer Eccentric Stud Set Screw
67	K3-67	Cloth Retainer Eccentric Stud Bushing
68	LD00524	Cloth Retainer Eccentric Stud Bushing Set Screw
69	K3-69	Cloth Retainer Stopper
70	LD00086	Cloth Retainer Stopper Set Screw
71		Feed Plate Assembly(Left)
72		Feed Plate Assembly(Right)
73	TH00027	Feed Plate Bracket Spring
74	K3-74	Feed Plate Bracket Spring Pin
75	LD00004	Feed Plate Bracket Spring Pin Set Screw
76	K3-76	Feed Plate Bracket Shaft
77	LD00004	Feed Plate Bracket Shaft Set Screw
78	K3-78	Feed Plate Bracket Shaft Spacer
79	K3-79	Feed Plate Bracket Shaft Thrust Collar
80	LD00004	Feed Plate Bracket Shaft Thrust Collar Set Screw
81	K3-81	Feed Plate Bracket Eccentric Shaft
82	LD00004	Feed Plate Bracket Eccentric Shaft Screw
83	K3-62-1	Fixture plate guide sheet

71	K3-71	Left presser foot bracket
	K3-71*1*2	Left presser foot
	K3-75-A	Left presser foot spring.
	LD00009	Presser foot screw
	LM00001	Presser foot nut

72	K3-72	Right presser foot bracket
	K3-72*1*2	Right presser foot
	K3-75-B	Right presser foot spring
	LD00009	Presser foot screw
	LM00001	Presser foot nut



Ref.Nos.	Parts No.	Description
1	FJ8-7	Screw Driver
2	FJ4-3	Spanner
3	FJ4-11	Wrench
4	BZ1-13	Needle
5	FJ4-8	Tweezers
6	FJ7-28	Oiler
7	K1-16-HX	Controller Pedal
8	FJ4-13	Machine Clamp Assembly
9	FJ4-14	Thread Guide
10	FJ7-26	Thread Guide Stud
11	FJ4-17	Knee Press Rod & Sleeve
12	K8-11-A	Thread Eyelet
13	LM00008	Nut
14	K1-61	Eye Guard Bracket
15	DQ00004	Washer
16	LD00501	Screw
17	K1-64	Screw
18	K1-60	Eye Guard Washer
19	K1-61-A	Eye Guard

Notes

[illegible]



Dealer: