

HUSQVARNA VIKING® H|CLASS™ E20

Master the Basics




- All-Purpose Foot
- Blind Hem Foot
- Buttonhole Foot
- Satin Stitch Foot
- Zipper Foot
- Quilting Foot
- Free-Motion/Darning Foot




Sell-up Features from HUSQVARNA VIKING® H|CLASS™ E10:

- 14 MORE DECORATIVE STITCHES - More stitches for sewing and decorating all your projects.
- 2 MORE PRESSER FEET - Free-Motion/Darning Foot - for excellent visibility and accuracy when free-motion quilting, embroidering or darning.
Quilting Foot - to give the perfect 1/4" seam that the quilter's need.
- ONE-STEP BUTTONHOLE - Makes buttonholes easier
- ADJUSTABLE STITCH WIDTH - Change stitch width to customize stitching to your projects.
- FEED TEETH DROP - Easily drop feed teeth for free-motion quilting and monograms.

Feature	Technique	Talk About
<p>Sews All Fabric Types and Weights</p> <p>(Kite-Tail – Jeans Hem)</p>	<p>FABRIC: Medium Woven, Tricot SELECT: Stitch Selector "A", Stitch Length 2.5 USE: All Purpose Foot SEW: Fold medium woven and tricot in half. Sew along the fold at 5/8" seam allowance.</p> <p>FABRIC: Denim SELECT: Stitch Length 3.0 SEW:</p> <ul style="list-style-type: none"> • Fold denim in half (wrong sides together). • Sew with fold at 5/8" seam allowance. • Fold seam to one side. • Topstitch down in place. • Fold up raw edge twice to form hem. • Sew hem in place. 	<ul style="list-style-type: none"> • The HUSQVARNA VIKING® H CLASS™ E20 sewing machine will sew all different types of fabrics, without having to change the tensions. • The adjustable presser foot pressure lets you sew on all types and weights of fabrics. • HUSQVARNA VIKING® H CLASS™ sewing machines will handle any of your heavy-duty projects such as hemming jeans, home dec, or craft sewing with specialty fabrics. • Electronic power provides a greater penetration power even at slower speeds, whether stitching one stitch at a time or at full speed.
<p>Easy Threading and Bobbin Winding</p>	<ul style="list-style-type: none"> • Show threading the top thread. • Show the additional spool pin for twin needle sewing. • Show where the bobbin is wound and the automatic bobbin stop. • Show the handy thread cutter. • Show how easy it is to load the bobbin from the front of the machine. 	<ul style="list-style-type: none"> • HUSQVARNA VIKING® H CLASS™ E20 sewing machine has the threading path printed on the machine. Watch how easy it is to thread. • Notice the handy thread cutter on the side. • The bobbin winder automatically disengages the needle for easy bobbin winding. • The automatic bobbin stop prevents over-winding. • A handy needle and thread information chart is included in the User's Guide.

Feature	Technique	Talk About
<p>Worry-Free Tension</p> 	<ul style="list-style-type: none"> Show the tension dial. Show how the normal range is indicated on the tension dial with a line between 3 and 5. 	<ul style="list-style-type: none"> For many types of fabrics, tension adjustment is not needed on your HUSQVARNA VIKING® H CLASS™ E20 sewing machine.
<p>Perfect Repeating Buttonholes</p> 	<p>FABRIC: Medium woven and stabilizer SELECT: Buttonhole of Stitch Selector dial, Buttonhole on stitch length dial, stitch width as desired (3 for narrow, 5 for wide)</p> <p>USE: Buttonhole Foot and Buttonhole Lever SEW:</p> <ul style="list-style-type: none"> Open the button plate in the back of the Buttonhole Foot and insert the button. Close the button plate to securely hold the button in place. Lower the Buttonhole Lever and gently push it back until it clicks. (This lever must be re-set for each buttonhole.) While lightly holding the upper thread, start sewing. The lower bartack will sew out first, then the left column followed by the top bartack, then the right column. When the stitches in the right column meet the lower bar tack, stop sewing. The buttonhole is complete. To make more buttonholes the same size, leave the button in place. Push the Buttonhole Lever back again until it clicks and repeat the sewing process. When all the buttonholes are finished, remove the Buttonhole Foot and push the buttonhole lever back up next to the needle clamp. 	<ul style="list-style-type: none"> The buttonhole is repeated easily by using the marked lines on the foot as a guide and by keeping the button in the back of the foot. This is great when you are sewing many buttonholes of the same length. <p>Show buttonhole samples on different types of fabrics.</p>
<p>Perfect Fabric Feeding Seam/Overcast Stitches (Simulated Serging)</p> 	<p>FABRIC: Sweatshirt fleece and ribbing SELECT: "Q" on Stitch Selector dial, stitch length "S", stitch width "5"</p> <p>USE: Satin Stitch Foot SEW:</p> <ul style="list-style-type: none"> Fold sweatshirt fleece in half and cut a small curve forming a neckline Fold ribbing in half lengthwise, stretch and sew on as a neckline. 	<ul style="list-style-type: none"> Sew the seam and overcast the edge at the same time to prevent raveling of the seam allowance on a woven fabric or to create a seam that will stretch on knit fabrics.

Feature	Technique	Talk About
<p>Easy Blind Hem</p> 	<p>FABRIC: Wool SELECT: "C" on Stitch Selector dial, stitch length 2.5, stitch width 3.0 USE: Blind Hem Foot SEW:</p> <ul style="list-style-type: none"> • Fold up a hem on a piece of wool. • Sew the hem with the fold riding along the guide of the foot, just catching the fold with the left swing of the needle as you stitch. • Adjust the stitch width and/or the guide on the Blind Hem Foot to catch just a thread from the fold. The stitch width adjustment allows you to accommodate different weights of fabric. 	<ul style="list-style-type: none"> • You can "fine tune" the blind hem with the stitch width button for different types of fabric since the HUSQVARNA VIKING® H CLASS™ E20 sewing machine has adjustable needle positions. It is also possible to adjust the guide on the foot.
<p>Needle Positions</p>	<p>FABRIC: Medium woven SELECT: "A" on Stitch Selector dial USE: All-Purpose Foot SEW:</p> <ul style="list-style-type: none"> • Show how the needle position changes by adjusting the stitch width dial. • Sew a row of stitching with the needle in the center needle position. • Turn stitch width dial to "5" for left needle position and sew a row of stitching next to the center needle stitching. 	<ul style="list-style-type: none"> • Multiple needle positions make it easy to sew with cording, piping or to put in zippers. • Topstitching, understitching, and edge stitching are also made easier with this feature. Perfect for garment sewing.
<p>Jam-Proof Bobbin</p>	<ul style="list-style-type: none"> • If this feature is important to the customer, demonstrate a HUSQVARNA VIKING® EMERALD™ or higher sewing machine. 	
<p>Easy Stitch Selection</p>	<ul style="list-style-type: none"> • Simply turn the stitch selection dial to select the stitch. (select K, L, M, N or O) 	<ul style="list-style-type: none"> • Just dial a stitch and you are ready to sew.
<p>Built-In Decorative Stitches</p>	<p>FABRIC: Medium woven and stabilizer SELECT: Select K,L,M,N, or O Stitch length "0" to "1" Stitch width "5" USE: Satin Stitch Foot SEW: Sew selected decorative stitch</p>	<ul style="list-style-type: none"> • Decorative stitches are a great way to add interest to a project or even embellish a ready-to-wear garment. <p>Show decorative stitch sample.</p>
<p>Alphabets/Monograms</p>	<p>FABRIC: Medium woven and stabilizer SELECT: "B" on stitch selector dial Stitch length close to "0" Stitch width at "5"</p> <p>SEW:</p> <ul style="list-style-type: none"> • Draw monogram letter with fade-away marker. • Sew slowly, following your drawn monogram. • Adjust the stitch width downward toward the "0" as you taper to a point. 	<ul style="list-style-type: none"> • The adjustable stitch width makes it easy to taper to a point. • Was this the type you were looking for? <p>Show monogram sample / lettering sample.</p>

Feature	Technique	Talk About
Machine Setting Advice	<ul style="list-style-type: none"> If this feature is important to the customer, demonstrate the HUSQVARNA VIKING® EMERALD™ or higher sewing machine. 	
Quilting Features	<p>Quilt Piecing: FABRIC: Woven Medium cotton SELECT: "A" on Stitch Selector dial Stitch length to 2.5 Stitch width to 0 USE: Quilting Foot and Guide SEW:</p> <ul style="list-style-type: none"> Line up raw edges of calico along toe to show how easy it is to sew a quarter inch seam. Using two pieces of Woven Medium cotton with quilt batting in between, show how to sew parallel rows of stitches. <p>Free-Motion/Darning Foot:</p> <ul style="list-style-type: none"> To show the free motion darning foot, use a screwdriver to remove the standard ankle. Attach the free motion darning foot. Make sure the lever of the foot is on top of the needle clamp screw. Lower the feed teeth for free motion quilting. The feed teeth lever is next to the bobbin case door. Move the lever to the right to lower the feed teeth. Move it back to the left to raise the feed teeth for normal sewing. 	<ul style="list-style-type: none"> The adjustable presser foot pressure allows for more space and fabric movement with heavier batting. Free motion quilting is easy when you lower the feed teeth and use the free motion darning foot. Use the feed teeth adjustment lever to lower the feed teeth.